



advanced FLOW engineering™
P.O. Box 1719
Corona, CA 92879
Support: 951-493-7100
www.aFePower.com

Intake kit Installation Instructions: 2007.5-2009 Dodge Ram 2500/3500 Cummins L6-6.7L (td)

Kit P/N: 51/54/75-81342 75-81342-0V			Tools Required: 9/16" socket or wrench 10mm socket or wrench 5/16" nut driver Flat head screwdriver Ratchet w/ extension 5/32" allen key T-20 torx bit (included) Pliers			Parts list: 1 Air filter (P/N Pro-GUARD 7™ 72-90038) 1 Housing, rotomold 1 Cover, rotomold 1 Tube, rotomold 1 Coupler, straight hi-temp 4" x 2-1/2" 1 Coupler, hump 6" x 3" 2 Clamp, #064 2 Clamp, #104 1 Screw, hex M6 x 1 x 20 2 Washer, fender 1 Nut, hex M6 4 Washer, wavy M6			Bonus Part List: (75-81342-0V Only) 1 Air filter P/N (Pro Dry S™ 21-90038) 1 Restore kit, gold squeeze 1 Pre-filter		
Make: Dodge	Year: '07.5-'09	Engine: L6-6.7L(td)									
Model: Ram 2500	Year: '07.5-'09	Engine: L6-6.7L(td)									
Model: Ram 3500	Year: '07.5-'09	Engine: L6-6.7L(td)									