



advanced FLOW engineering™  
P.O. Box 1719  
Corona, CA 92878  
Support: 951-493-7100  
aFepower.com

## Intercooler Tube Installation Instructions: 2010 Dodge Ram Cummins Intercooler Tube Upgrade L6-6.7L (td)

Kit P/N: 46-20089

Make: Dodge

Model: Year: Engine:

Ram 2500 2010 L6-6.7L(td)

Ram 3500 2010 L6-6.7L(td)

### Tools Required:

7/16" deep socket

3/16" hex key

### Parts list

1 Tube, Upgrade - 05-60048

1 Coupler, hump 3-1/2" - 05-60025

1 Coupler, hump 3" - 05-60012

2 Clamps, spring 3-1/2" - 05-60013

2 Clamps, spring 3-3/4" - 05-60024

2 Plugs, hex head socket (1/8" NPT) - 03-50029



Complete Kit

Step 1



Complete Stock Intercooler tube.

Step 2



With 7/16" deep socket, loosen clamp on intercooler.

Step 3



With 7/16" deep socket, loosen clamp on manifold. Push down on intercooler tube and disconnect from manifold. Remove stock intercooler tube from vehicle.

Step 4



Install plugs in to 1/8" NPT ports with 3/16" hex key.

Step 5



Install 3" hump coupler with clamps provided to new tube.

Step 6



Install 3-1/2" hump coupler to manifold with clamps provided.

Step 6



Install new tube and position into coupler on manifold. Tighten and torque all four clamps to 75 in-lbs. **Check and tighten after 50 miles!** Your Intercooler tube installation is now complete. Thank you for choosing aFe power!