

PLEASE READ BEFORE STARTING INSTALLATION


While MBRPinc. has made every effort to ensure that all components of this system are of superior quality and properly packaged, it is the installer's responsibility to ensure the following before removal of the factory exhaust:

- that ALL components shown in the illustration on page 2 are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the system you have purchased is appropriate for your vehicle year, model and configuration.
- that the system will not interfere with any modifications previously installed.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this system to your vehicle please contact your dealer before commencing installation.

Installation Instructions for System S6118AL

2004.5-2006 Dodge Cummins "600/610" 5" Diesel Exhaust System Kit – Cat Back Single



S6118AL "Installer Series"


- 1 PC - 4" to 5" Adapter
 - 1 PC - Extension Pipe
 - 1 PC - High Flow Muffler
 - 1 PC - Tail Pipe
 - 1 PC - 4" Clamp
 - 3 PCS - Hanger Clamps
- Tips Sold Separately**

Removal of stock system:

1. Apply a penetrating lubricant liberally to all exhaust fasteners, hangers and rubber insulators.
2. Remove the exhaust system from the rubber insulators and remove all of the clamps from the catalytic converter back.
3. Separate the slip joint behind the muffler and remove the tail pipe. Next, separate the slip joint located behind the catalytic converter and remove the muffler and extension pipe.
4. Remove the spare tire. You may not be able to reinstall your spare tire after the installation of this exhaust system.

Installation of MBRP Inc. Performance Exhaust:

1. Install the **4" to 5" Adapter** over the OEM pipe behind the catalytic converter. Install the **Extension Pipe** onto the **4" to 5" Adapter**. This provides the required length to fit a quad cab long bed or mega cab truck. The **Extension Pipe** will have to be cut to fit all other vehicles.
Installation Tip: Temporarily install the **Muffler** and **Tail Pipe** using the factory rubber insulators and the **Hanger Clamp**. Measure from the **Muffler** to the **4" to 5" Adapter** to determine the length required. Cut the pipe to the required length.



2. Install the **Muffler** over the **Extension Pipe** so that the exhaust will flow smoothly over the louvers. Refer to the illustration on the left.
3. Install the **Hanger Clamp** into the OEM rubber hanger located on the frame near the inlet of the **Muffler**.
4. Remove the factory rubber insulator for the factory tail pipe and install it onto the **Tail Pipe** hanger. Install the **Tail Pipe** from the rear of the truck, over the axle and attach to the outlet of the **Muffler**. Finish hanging the **Tail Pipe**.
5. Install the **Hanger Clamp** into the two OEM rubber hangers located above the outlet of the **Muffler**.
6. Install the provided clamps around pipes where needed. Adjust the **Tail Pipe** and check along the whole length of the exhaust system to ensure there is adequate clearance around the fuel and brake lines or any wiring. If any interference is detected relocate or adjust.
7. Make sure that the exhaust is properly in place before tightening clamps. Start at the front of the exhaust system and begin tightening all connections.
8. If a tip has been purchased, install and adjust to suit. Using a 17mm wrench tighten the lock bolt located on the **Tip**. **A Tip is not included with this kit**. Tips may be purchased separately, check with your dealer.

Congratulations! You are ready to begin enjoying the improved performance and driving experience of your MBRP Inc. performance exhaust system. We hope you enjoy your purchase.