

INSTALLATION INSTRUCTIONS

2010 DODGE 3/4 AND 1 TON

BRUSHGUARD

TOOLS REQUIRED:

- | | |
|------------------------|--------------------------|
| (1) 1/2" DRIVE RATCHET | (1) 18MM DEEPWELL SOCKET |
| (1) 3/8" DRIVE RATCHET | (1) 3/4" WRENCH |
| (1) 3/4" SOCKET | |

INSTALLATION OF BRUSH GUARD

1. USING 15MM SOCKET, REMOVE 4 TOWLOOP MOUNTING NUTS ON DRIVERS SIDE.
2. REPEAT STEP 2 FOR PASSENGER SIDE
3. INSTALL BRUSH GUARD TO FACTORY BUMPER WHERE TOW LOOPS **WERE** MOUNTED WITH PROVIDED BOLTS, ALIGN AND TIGHTEN ALL BOLTS SECURELY.
4. USING THE HOLES PROVIDED REINSTALL THE FACTORY TOW LOOPS TO THE BRUSHGUARD.