

# **INSTALLATION INSTRUCTIONS**

## **2010-2015 DODGE 4500/5500**

### **BRUSHGUARD**

#### **TOOLS REQUIRED:**

- (1) 1/2" DRIVE RATCHET
- (1) 3/4" WRENCH
- (1) 3/4" SOCKET

#### **INSTALLATION OF BRUSH GUARD**

1. INSTALL BRUSH GUARD TO FACTORY FRAMEHORN BETWEEN BUMPER
2. INSTALL SUPPLIED BOLTS, NUTS & WASHERS TO FACTORY HOLES THROUGH BRUSH GUARD BRACKETS
3. ALIGN AND TIGHTEN BOLTS