

INSTALLATION INSTRUCTIONS

2008-10 FORD SUPERDUTY
BRUSH GUARD PART# **BG0800F**

2011-2015 FORD SUPERDUTY
BRUSH GUARD PART# **BG2011F**

TOOLS REQUIRED:

- (1) 1/2" DRIVE IMPACT WRENCH
- (1) 1/2" DRIVE 18MM SOCKET
- (1) 1/2" DRIVE 3/4" SOCKET

1. **USING 18MM SOCKET**, REMOVE 2 BUMPER MOUNTING BOLTS FROM EACH SIDE.
2. INSTALL SUPPORT BRACKET USING SUPPLIED BOLTS TO FRAME, **DO NOT TIGHTEN** BOLTS AT THIS TIME.
3. REPEAT STEP 2 ON PASSENGER SIDE.
4. INSTALL BRUSH GUARD USING SUPPLIED 1/2" X 2-1/2" BOLTS. **ALIGN AND TIGHTEN.**
5. **MAKE SURE THAT THE BRUSH GUARD IS PROPERLY ALIGNED AND TIGHTEN SUPPORT BRACKET TO THE FRAME SECURELY.**

Thank you for using Tough Country Products