

**INSTALLATION INSTRUCTIONS**  
**2007 TOYOTA TUNDRA SR5**  
**BG0777T & BG0714T 2014-2016 TUNDRA**

**TOOLS REQUIRED:**

- |                              |                 |
|------------------------------|-----------------|
| (1) 1/2" DRIVE IMPACT WRENCH | (1) 14MM WRENCH |
| (1) 17MM SOCKET              | (1) 3/4" WRENCH |
| (1) 3/4" SOCKET              |                 |

**BRUSH GUARD INSTALLATION:**

1. USING **17MM SOCKET**, REMOVE TOW LOOPS.
2. PLACE MOUNTING BRACKET IN TOW LOOP HOLES MAKING SURE THAT THE BIG SIDE OF BRACKET IS TO THE OUTSIDE OF THE TRUCK, AND RE-INSTALL TOW LOOPS WITH FACTORY BOLTS.
3. REMOVE TOP OUTSIDE BOLT ON FRAME USING **14MM SOCKET**
4. MOUNT TOP SUPPORT BRACKET BY SLIDING IT THROUGH OUTSIDE SLOT IN BUMPER AND SECURE WITH FACTORY NUT.
5. USING **3/4" WRENCH** AND SOCKET, MOUNT BRUSH GUARD TO INSTALLED MOUNTING BRACKETS WITH SUPPLIED BOLTS.
6. ADJUST TO STRAIGHTEN BRUSH GUARD, AND TIGHTEN SECURELY.

**THANK YOU FOR USING TOUGH COUNTRY PRODUCTS**

