

INSTALLATION INSTRUCTIONS

2010-2013 DODGE 2500/3500

TB1034D, DTB1034D

TOOLS REQUIRED	15MM SOCKET
3/4" SOCKET	RATCHET
3/4 WRENCH	SCREWDRIVER

1} USING A SCREWDRIVER REMOVE LICENSE PLATE

2} FROM UNDERNEATH TRUCK REMOVE 2 - 15MM BOLTS FROM EACH SIDE OF BUMPER

3} UNPLUG WIRING FROM 7 WAY PLUG.
REMOVE LICENSE PLATE LIGHTS AND
DISCONNECT LIGHTS

4} FROM THE FRONT OF BUMPER, REMOVE THE 2 - 15MM BOLTS AND CAREFULLY REMOVE BUMPER.

5} INSTALL TOUGH COUNTRY BUMPER ON TRUCK USING THE SUPPLIED 1/2"X 2 BOLTS [ON 2013 MODELS YOU WILL NOT USE THE CENTER HOLE]

6} ALIGN BUMPER AND TIGHTEN.

7} REINSTALL LICENSE PLATE ON BUMPER.