

INSTALLATION INSTRUCTIONS
DODGE 1500,2500,3500 AND MEGA CAB 2003-2009
(GASOLINE AND *DIESEL* MODELS)
TRADITIONAL FRONTS: TFR0217D, TFR0209D, TFR2006D
APACHE FRONTS: AFR0027D, AFR0028D, AFR0615D, AFR2006D
DELUXE FRONTS: DFR0615D, DFR0024D, DFR0022D, DFR2006D

REMOVAL OF FACTORY BUMPER

TOOLS REQUIRED:

½ DRIVE IMPACT, 18MM DEEP WELL SOCKET, 10MM SOCKET AND WRENCH, NEEDLE NOSE PLIERS.

NOTE: 3/8" WRENCH IF FRONT LISCENCE PLATE IS REQUIRED.

1. ***USING 3/8" WRENCH**, REMOVE LISCENCE PLATE
2. RAISE HOOD TO EXPOSE BACKSIDE OF FRONT BUMPER
3. REMOVE FOGLIGHT CONNECTOR FROM RETAINING CLIP ON BUMPER THEN DISCONNECT CONNECTOR FROM WIRING HARNESS. **USING 18MM SOCKET**, REMOVE 2 BUMPER MOUNTING BOLTS FROM PASSENGER SIDE.
4. REPEAT STEP 3 ON DRIVERS SIDE OF TRUCK.
5. *(DIESEL ONLY) USING 10MM SOCKET, REMOVE 2 CORE SUPPORT BOLTS TO EXPOSE BUMPER MOUNTING BOLTS.*
6. *(DIESEL ONLY) LIFT CORE SUPPORT UP AND PUSH FORWARD TO REMOVE BOLTS.*
7. *TO REMOVE BUMPER, PUSH DOWN AND PULL OUT.*
8. **USING 10MM SOCKET AND WRENCH**, REMOVE 3 BOLTS ON EACH FOGLIGHT FROM BUMPER.
9. **USING NEEDLE NOSE PLIERS**, PULL OUT RETAINING CLIPS TO REMOVE FOGLIGHT WIRING HARNESS.

RE-INSTALLATION OF FOGLIGHTS (IF APPLICABLE) AND REPLACEMENT BUMPER

1. INSTALL FOGLIGHTS ON REPLACEMENT BUMPER USING ORIGINAL MOUNTING BOLTS WITH **10MM SOCKET AND WRENCH**.
2. INSTALL REPLACEMENT BUMPER USING ORIGINAL MOUNTING BOLTS AND NUTS WITH **18MM SOCKET**. ***ENSURE PROPER POSITION AND TIGHTEN SECURELY.**
3. *(DIESEL ONLY) RE-INSTALL CORE SUPPORT BOLTS USING 10MM SOCKET.*
4. INSTALL FOGLIGHT WIRING HARNESS BY FIRST CONNECTING DRIVER SIDE FOGLIGHT, THEN LOOP AROUND OUTER LIGHT BRACKET AND STRETCH TOWARD PASSENGER SIDE.
5. PUSH HARNESS RETAINING CLIPS INTO HOLES ON BOTTOM SIDE OF CORE SUPPORT BRACKET, AND TAKE UP REMAINING SLACK BY LOOPING OVER PASSENGER LIGHT BRACKET.
6. CONNECT PASSENGER FOGLIGHT.
7. ***RE-INSTALL LISCENCE PLATE IF REQUIRED.**

THANK YOU FOR USING TOUGH COUNTRY PRODUCTS