

## INSTALLATION INSTRUCTIONS

### 2008-12 FORD SUPER DUTY

**DFR0800F, AFR0800F, TFR0800F, EFR0800F, DFR2011F, AFR2011F, TFR2011F, EFR2011F**

#### **TOOLS REQUIRED:**

- |                                 |                                        |
|---------------------------------|----------------------------------------|
| (1) 1/2" DRIVE IMPACT WRENCH    | (1) 1/2" DRIVE 18MM SOCKET             |
| (1) 3/8" DRIVE RATCHET          | (1) 8MM SOCKET                         |
| (1) 15MM SOCKET                 | (1) 13MM SOCKET                        |
| (1) 3/4" WRENCH                 | (1) 3/8" DRIVE 3" EXTENSION            |
| (1) MEDIUM PHILLIPS SCREWDRIVER | (1) *HACKSAW (OR SIMILAR CUTTING TOOL) |
| (1) 10MM WRENCH                 |                                        |

#### **BUMPER REMOVAL INSTRUCTIONS:**

1. UNPLUG CONNECTOR ON DRIVERS SIDE; ABOVE THE BUMPER FOR FOGLIGHTS. **\*(IF EQUIPPED)**
2. USING 8MM SOCKET, REMOVE HOOD LATCH. **\*(IF MOUNTED TO BUMPER)**
3. USING 13MM SOCKET, REMOVE BUMPER SUPPORT BOLTS FROM UNDERNEATH BY FENDER ON EACH SIDE OF TRUCK.
4. USING 18MM SOCKET, REMOVE THE 4 BUMPER MOUNTING BOLTS.

**[\*NOTE: AFTER REMOVING THE FIRST BOLT, INSERT SCREWDRIVER INTO BOLT HOLE TO PREVENT NUT PLATE FROM SPINNING INTO FOG LIGHT (IF EQUIPPED) WHILE REMOVING SECOND BOLT.]**

5. CAREFULLY REMOVE BUMPER.
6. USING 8MM SOCKET, REMOVE 6 BOLTS AND WIRING HARNESS FROM FOG LIGHTS. **\*(IF EQUIPPED)**
7. USING 15MM SOCKET, REMOVE FACTORY TOW LOOPS.

#### **INSTALLATION OF TOUGH COUNTRY REPLACEMENT BUMPER WITH FOG LIGHTS:**

##### **\*NOTE\* (IF EQUIPPED)**

**FOG LIGHTS WILL BE INSTALLED ON OPPOSITE SIDES THAN THEY WERE TAKEN OFF. EACH FOG LIGHT BRACKET WILL BE LABELED ON LIGHT SIDE AS (LH) FOR LEFT HAND AND (RH) FOR RIGHT HAND.**

1. STARTING WITH PASSENGER SIDE; FOG LIGHT LABELED WITH (LH), AND FOG LIGHT FACING AWAY FROM YOU, THERE WILL BE 2 MOUNTING LEGS USED ON THE BRACKET. THE FOG LIGHT PLUG WILL FACE THE OUTSIDE OF THE TRUCK. USING THE HACKSAW CUT OFF THE UNUSED LEG OF THE FOG LIGHT MOUNTING BRACKET. USE FACTORY BOLTS AND SUPPLIED NUTS. TIGHTEN SECURELY.
2. REPEAT STEP (1) FOR DRIVERS SIDE.

#### **INSTALLATION OF TOUGH COUNTRY REPLACEMENT BUMPER:**

1. INSTALL REPLACEMENT BUMPER USING SUPPLIED 1/2" X 2" BOLTS IN THE BACK HOLE ON THE FRAME. USE THE SUPPLIED 1/2" X 2" BOLTS IN THE FORMER TOW LOOP MOUNT POSITION HOLES. TIGHTEN SECURELY.
2. INSTALL FACTORY TOW LOOPS ON TOP OF REPLACEMENT BUMPER TOW LOOP MOUNTING BRACKET WITH FLANGE TO THE INSIDE OF THE FRAME FACING THE CENTER OF THE TRUCK.
3. RECONNECT HARNESS TO FOG LIGHTS (IF EQUIPPED).
4. **\*(IF EQUIPPED WITH WINCH MOUNT, REMOVE FLANGE FROM TOW LOOPS).**

THANK YOU FOR USING TOUGH COUNTRY PRODUCTS.