

## **INSTALLATION INSTRUCTIONS**

### **POLARIS 900 GAS**

### **2013 POLARIS FRONT REPLACEMENT**

#### **TOOLS NEEDED:**

RATCHET

15MM SOCKET

#### **SUPPLIED PART:**

2x Pipe Spacers

#### **FACTORY BUMPER REMOVAL:**

1. USING 15MM SOCKET, REMOVE UPPER MOUNTING BOLTS LOCATED ON SIDE OF FRAME AND SET BOLTS ASIDE.
2. USING 15MM SOCKET, REMOVE 2 BOLTS FROM BOTTOM OF BUMPER AND SET BOLTS ASIDE.
3. REMOVE BUMPER.

#### **INSTALLATION OF REPLACEMENT BUMPER:**

1. SET BUMPER IN PLACE, INSERT SPACER IN BETWEEN FRAME. INSERT FACTORY BOLTS INTO SIDE OF FRAME THROUGH THE SPACER AND HAND TIGHTEN.
2. INSTALL FACTORY BOLTS INTO BOTTOM HOLES AND HAND TIGHTEN.
3. PROPERLY ALIGN BUMPER AND TIGHTEN ALL BOLTS SECURELY.

**THANK YOU FOR CHOOSING TOUGH COUNTRY BUMPERS**