

INSTALLATION INSTRUCTIONS

KAWASAKI MULE 4010

2008-2016

TOOLS:

PHILLIPS SCREWDRIVER

RATCHET

15MM SOCKET

12MM SOCKET

3/4" SOCKET

5/8" SOCKET

11/16" SOCKET

****IF NOT EQUIPPED WITH FACTORY BUMPER, PROCEED TO REPLACEMENT INSTALLATION****

FACTORY BUMPER REMOVAL:

1. REMOVE PLASTIC COVER SCREWS USING PHILLIPS SCREWDRIVER.
2. USING 12MM SOCKET, REMOVE 2 UPPER BUMPER MOUNTING BOLTS
3. USING 15MM SOCKET, REMOVE 2 LOWER BUMPER MOUNTING BOLTS.
4. REMOVE FACTORY BUMPER.

REPLACEMENT BUMPER INSTALLATION:

****REMOVE PLASTIC COVER SCREWS ON SOME MODELS IF NOT EQUIPPED WITH FACTORY BUMPER****

1. SET BUMPER IN PLACE AND USING 15MM FACTORY BOLTS ON BOTTOM BUMPER MOUNTING BRACKET AND HAND TIGHTEN ONLY.
*** IF NOT EQUIPPED WITH FACTORY BUMPER, USE SUPPLIED 1/2" X 4" BOLTS***
2. USING SUPPLIED 1/2" X 1 BOLTS, INSTALL INTO TOP OF LOWER BUMPER MOUNTING BRACKET AND HAND TIGHTEN ONLY.
3. INSTALL SUPPORT BRACKET ON OUTSIDE OF MULE FRAME TO INSIDE OF REPLACEMENT BUMPER FRAME USING FACTORY BOLT IF SUPPLIED, OR USE SUPPLIED 7/16" X 1-1/2" BOLT THROUGH HOLE IN BUMPER FRAME AND HAND TIGHTEN ONLY.
4. USING FACTORY 12MM BOLT, BOLT SUPPORT BRACKET TO MULE FRAME AND HAND TIGHTEN ONLY.
5. ENSURE PROPER ALIGNMENT AND TIGHTEN ALL BOLTS SECURELY.

THANK YOU FOR CHOOSING TOUGH COUNTRY BUMPERS