

INSTALLATION INSTRUCTIONS
KAWASAKI MULE 4010
2006-2016 MULEBB

TOOLS REQUIRED

DRILL DRIVER	13/32 DRILL BIT
2 CLAMPS	RATCHET
CENTER PUNCH	TAPE MEASURE
9/16 WRENCH	9/16 SOCKET

INSTALLATION OF BUMPER

- 1] INSTALL BUMPER UNDERNEATH BED RAILS TO DESIRED AREA. USING THE CLAMPS; CLAMP BUMPER ON RAILS.
- 2] LIFT BED TO ASSURE PROPER CLEARANCE BETWEEN TIRES AND BUMPER. CLOSE BED TO LOCKING POSITION AND ADJUST ACCORDINGLY.
- 3] OPEN THE TAILGATE TO ASURE PROPER CLEARANCE.ADJUST IF NECESSARY.
- 4] CENTER PUNCH ALL FOUR HOLES IN CENTER OF RAILS.
- 5] REMOVE BUMPER; DRILL ALL HOLES.
- 6] INSTALL BUMPER WITH PROVIDED 3/8 X 2 BOLTS AND HARDWARE.ALIGN AND TIGHTEN.