

S3 High Clearance Lower A-arms

Installation Notes

1. The lower ball joint pinch bolt must be replaced with the included M10-1.5x50mm bolt and M10 lock nut.
2. Also the tie rod end bolt needs to be installed from the bottom.

These steps are necessary to insure that there is no rubbing on the a-arms.

