



2019+ Honda Talon
2" Receiver Hitch # S3193



INSTALLATION INSTRUCTIONS

**Honda Talon – 2”
Receiver Hitch**



2019+ Honda Talon 2" Receiver Hitch # S3193

PARTS LIST

ITEM	PART #	DESCRIPTION	QTY
	S3193	2" Receiver Hitch	1

INSTALLATION

- 1.) Place the vehicle in park on a flat level surface.
- 2.) Remove the 4 rear inner radius rod nuts using a 17mm socket and a 17mm wrench as backup. Do not remove the bolts. (See picture A)
- 3.) Install the S3 2" Receiver Hitch onto the bolts, taking care to not push the bolts through.
- 4.) Reinstall the nuts and tighten to factory torque specs. Red threadlocker is recommended.
- 5.) Test drive vehicle and check all hardware.

Thank you for choosing S3 Power Sports! Let us know if you have any questions! 855-221-7097

