Installation Instructions Page 1 of 4



2019+ Honda Talon R High Clearance Front Lower A-Arms # S3188



Honda Talon — High Clearance Front Lower A-arms

Installation Instructions Page 2 of 4



2019+ Honda Talon R High Clearance Front Lower A-Arms # S3188

PARTS LIST

ITEM	PART#	DESCRIPTION	QTY
	S3188	Passenger Lower Arm	1
	S3188	Driver Lower Arm	1
	11332	HD Bushing	8
	11333	Pivot Tube	4

- 1.) Place Talon in park (P) on a flat level surface and elevate the front of the machine. Support the vehicle on suitable jack stands.
- 2.) Remove front tires.
- 3.) Remove cotter pin from lower ball joint castle nut.
- 4.) Remove castle nut using 14mm socket.
- 5.) Disconnect OEM lower arm from ball joint. (Pro Tip: Do not hammer on ball joint or castle nut. Use a pry bar between arm and hub while tapping on arm with rubber hammer. Be careful to not damage ball joint boot. Alternately, you can screw the castle nut on backwards and tap the base of the nut while prying on the arm.) See picture A and B.
- 6.) Noting orientation of the 2 bolts, remove lower arm using 17mm socket and 17mm wrench.
- 7.) Install provided GREASELESS bushings and pivot tubes. No greasing required. (*Pro Tip : Use a vice to press the bushings and pivot tube in, taking care to not damage powder coat.*)
- 8.) Install lower arm using the stock hardware, referring to bolt orientation noted earlier. See picture C and D. Do not tighten. (Note: Arms are side specific.)
- 9.) Raise arm into lower ball joint and reinstall castle nut.
- 10.) Tighten the a-arms bolts and castle nut to factory spec. (*Pro Tip : Red threadlocker is recommended.*)
- 11.) Reinstall cotter pins.
- 11.) Repeat this process on opposite side.
- 12.) Reinstall front tires to factory spec and remove from jack stands.
- 13.) Test drive machine and recheck all fasteners and lug nuts.

Thank you for choosing S3 Power Sports! Let us know if you have any questions! 855-221-7097

Installation Instructions Page 3 of 4



2019+ Honda Talon R High Clearance Front Lower A-Arms # S3188





Picture B



Installation Instructions Page 4 of 4



2019+ Honda Talon R High Clearance Front Lower A-Arms # S3188

Picture C



Picture D

