



DEVIANT
RACE PARTS

Canam X3 Door handle install instructions.



Tools you may need:

- Drill
- 3/16" Drill bit
- 10MM Socket
- 3/8" Ratchet
- 10MM End Wrench
- T30 Torx

1. Remove the plastic cover from the latch with a T30 Torx bit. Now you can drill out the rivet retaining the factory tether.



2. With the tether removed use the supplied hardware and install the new door handle as shown.



3. Tighten the two bolts and repeat the steps for the other door.



Canam door handle check list

- (2) Door handles
- (4) M6 Bolts
- (4) M6 Nuts
- (8) M6 Washers

Packaged By: _____ Date: _____

