Installation Instructions Page 1 of 6



2017+ Maverick X3 Nerf Bars # S3127



INSTALLATION INSTRUCTIONS

Maverick X3 – Nerf Bars

Installation Instructions Page 2 of 6



2017+ Maverick X3 Nerf Bars # \$3127

PARTS LIST

ITEM	PART#	DESCRIPTION	QTY
		Passenger Side Nerf Bar	1
		Driver Side Nerf Bar	1
		Curved Washers	12
		2.75" Grade 8 Bolts	6
		Finishing Plug	4
	11122	Spacer (Xrc only)	2
		3.5" Grade 8 Bolts (Xrc only)	2

^{**}Note – Tree Kicker Nerf Bars will use additional hardware: (2) M10-1.5x55mm bolts, (4) M10 flat washer, and (2) M10-1.5 nylock nut.

- 1.) Start by placing X3 on flat ground and be sure machine is in Park (P).
- 2.) Find small divots in side panel plastics that will notate where preset holes in the frame are. (See Image A)
- 3.) Find the mounting holes in the frame and familiarize yourself with where the bolts will go through. (Figure B & C)
- 4.) Use a "step bit" to drill through the plastics to allow nerf bar mounting point to go through. **Drill ¼" higher than the divot itself. From what we have found by installing numerous sets in the shop, the plastics tend to sag which makes the holes in the frame higher than the divots**. Holes need to be approximately 1". Maybe a little larger to account for frame variance but start with 1". (Figure D)
- 5.) Place nerf bar against side of machine to make sure these holes line up with mounting points.
- 6.) Place supplied Grade 8 Bolt through supplied curved washer and through frame rail from inside to outside of frame. Place curved washer on opposite side of frame over the bolt.

^{***}Note – Xrc Models will come with (2) additional spacers and (2) 3.5" long bolts for the front most mount.

Installation Instructions Page 3 of 6



2017+ Maverick X3

Nerf Bars # \$3127

- 7.) Start the bolts into the nerf bars by hand. Once these are started, use RED Loctite and tighten each of the 3 bolts till they are snug.
- 8.) Do the same process on the opposite side.
- 9.) Drive machine around for a few minutes and check all bolts to make sure everything is tight.

Installation Instructions Page 4 of 6



2017+ Maverick X3 Nerf Bars # S3127

Installation Instructions Page 5 of 6



2017+ Maverick X3 Nerf Bars # S3127

The image part with relationship ID rid10 was not found in the file.	
	Figure B
th relationship ID 1/d10 was not found in the file.	
	Figure C

Installation Instructions Page 6 of 6



2017+ Maverick X3 Nerf Bars # S3127

The image part with relationship ID rid10 was not found in the file.	