

INSTALLATION INSTRUCTIONS

2017-C CAN-AM DEFENDER

IF EQUIPPED WITH WINCH YOU WILL NEED TO PURCHASE A FAIRLEAD MOUNTING BRACKET AND LONGER BOLTS TO REINSTALL WINCH

1. IF EQUIPPED WITH WINCH. REMOVE FAIRLEAD SET ASIDE.
2. REMOVE 4 WINCH BOLTS AND MOTOR WIRES; SET WINCH ASIDE
3. INSTALL TOUGH COUNTRY BUMPER ON THE 6 HOLES IN FRONT, USING THE SUPPLIED BOLTS AND HARDWARE
4. ALIGN BUMPER AND TIGHTEN BOLT.
5. IF EQUIPPED WITH WINCH. REROUTE THE WINCH CABLES FROM SOLENOID TO ACCOMMODATE DISTANCE.
6. INSTALL WINCH AND WINCH PLATE TO BUMPER
7. CONNECT WIRE BACK ONTO WINCH MOTOR

THANK YOU FOR CHOOSING TOUGH COUNTRY