



INSTALLATION INSTRUCTIONS

Fold Down Glass Windshield: for Polaris® General™

- Do not discard packaging until product has been successfully installed.
- SuperATV does not recommend keeping Windshield installed while transporting on an open air trailer. Remove or secure with straps.



(Kit contents continue on following page)

Need help with your installation?



sales@superatv.com



www.superatv.com



1-855-743-3427




8:00am - 8:00pm EST M-Th
8:00am - 7:00pm EST Friday
9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

*Thank You
For Choosing*

SUPERATV.COM

(Kit contents continued)



Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.



By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.


Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.


- Install Foam and D-Seal to locations shown.





- Remove (1) stock bolt from Cage.
- Install provided Stud.
- Remove remaining bolt.
- Repeat for opposite side.



- Install Lower Mount onto Studs and Cage.
- **Do not remove Studs.** Secure Lower Mount with hardware shown. Repeat for opposite side; do not tighten.
- Remove Studs and add hardware shown; do not tighten.




- Install Upper Mount and Upper Filler to Frame with hardware shown; do not tighten.




- Install Strap to Hood Mount - L with hardware shown; tighten.
- Install Bumper to Hood Mount - L.
- Repeat steps for Hood Mount - R.

- Place Hood Mount - R onto machine in location shown.
- Measure over approximately 1-3/4".
- Mark hole locations in Hood Mount - R onto plastic.
- Remove Hood Mount - R and drill holes through plastic. Holes to be large enough for 6mm bolts.




- Repeat steps for driver side.


- Secure Hood Mount - L to machine with hardware shown; tighten.
- Repeat for passenger side.




- Install D-Seal to Windshield.




- Separate Cam Latches and install to Windshield; tighten.
- Separate components shown from Wiper and assemble to Windshield; tighten.



- Install Wiper and Handle; tighten.



- Place Windshield onto machine.
- Secure Windshield to Hinges on Lower Mount with hardware shown; tighten.



- Engage Latches and align Windshield to machine.
- TIGHTEN ALL HARDWARE.



- When Windshield is in open position, secure Windshield to Hood Mounts with previously installed Straps.



- Install Grommet into Windshield.

