



1.877.287.8634

INSTALLATION INSTRUCTIONS

IMPORTANT NOTICE: Be sure to inspect and test fit product before having it coated or painted. Ranch Hand will not be responsible for the cost of the coating if any problems with fit or finish are not noted and addressed beforehand.

**1988-98 CHEVY/GMC PICKUP
1992-99 TAHOE, SUBURBAN & YUKON
PART # FBC881BLR**

1. Remove the factory bumper.
2. Slide the mounting brackets into the frame. Use three- $\frac{1}{2}$ x 2 $\frac{1}{4}$ " bolts, on each side of the front bumper replacement, to install. *NOTE: The nuts go to the inside of the frame.*
3. Raise the front bumper replacement until it is level.
4. Tighten all bolts.
5. Mount the license plate to the bracket that is welded to the receiver hitch. Use the $\frac{1}{4}$ " bolts and nuts to install.
6. ***MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!***

----- **WARNING** -----

Special care should be exercised in the handling, storage and installation of Ranch Hand equipment.

The actual weight of each piece of equipment will vary depending on style and model. The weight of the equipment is sufficient in volume to warrant special care, assistance and in some instances, the use of mechanical equipment during the transfer and installation of the equipment. Do not assume a position directly under the equipment during installation. Be sure the equipment has been connected and stabilized during installation to prevent falling or shifting of positions.

Periodically check tightness of bolts to make sure they are tight, and unlikely to fail.

Rev. 2021