

INSTALLATION INSTRUCTIONS

<u>IMPORTANT NOTICE</u>: Be sure to inspect and test fit product before having it coated or painted. Ranch Hand will not be responsible for the cost of the coating if any problems with fit or finish are not noted and addressed beforehand.

2005-07 FORD SUPER DUTY / 2005-06 EXCURSION PART # GGF051BL1 (GRILL GUARD)

- 1. Remove the four 18mm bumper bolts. Install the grill guard by using the same 18mm bolts. Hand tighten.
- 2. Place the bottom mounting bracket between the top side of the grill guard strap and the bottom side of the blocker beam. Use the $\frac{1}{2}$ " x 1 $\frac{1}{2}$ " bolts to install. Hand tighten.
- 3. Center the grill guard from side to side and make sure grill guard is level. Tighten the four 18mm bolts and then the ½" bolt.
- 4. MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!