

INSTALLATION INSTRUCTIONS

<u>IMPORTANT NOTICE</u>: Be sure to inspect and test fit product before having it coated or painted. Ranch Hand will not be responsible for the cost of the coating if any problems with fit or finish are not noted and addressed beforehand.

2016 FORD SD (F-250/F-350) SPORT BACK BUMPER PART # SBF161BLSL

Note: The notched section of the step plate lip needs to be cut out for Duallies.

Note: If reverse sensors are present, remove the sensors from the factory bumper. Do not disconnect the sensor wires. Zip-tie the sensors to the frame to prevent damaging when installing the bumper.

- 1. Unplug the license plate lights and remove the factory bumper.
- 2. If reverse sensors are present. Remove the four plastic plugs from the skirts and install the rubber grommets.
- 3. Mount the license plate to the bumper with four 1/4" bolts.
- 4. Mount the two license plate lights into the matching 1½" holes in the back plate.
- 5. Slide the Sport bumper in place. The mounting brackets will mount to the outside of the frame.
- 6. Use the ½" x 1 ½" bolts to mount the mounting bracket to the frame.
- 7. Install the sensors into the rubber grommets. You may want to use a small amount of silicon to help secure the sensor in the grommet.
- 8. MAKE SURE ALL NUTS AND BOLTS ARE TIGHT!