



# INSTALL INSTRUCTIONS FOR 82-1007

[PRINT](#)

## BEFORE YOU START

Thank you for purchasing your new S&B Filters Map Spacer. If at any time you need additional assistance with installation or have any other questions or comments, feel free to call our customer support team at **909-947-0015**.

## REQUIRED TOOLS

- 5mm Allen Wrench/Bit
- 10mm Socket with Ratchet
- Blue Loctite
- Torque Wrench (inch pounds)

**Approx. Install Time:** 15 min



Hi. Need any help?



[Cookie Preferences](#)

## STEP 1:

Use a 10mm socket to remove the bolt holding on the stock lower MAP Sensor.



## STEP 2:

Remove the stock sensor from the manifold.



## STEP 3:

Put some blue loctite on the stock MAP sensor bolt. Then mount the stock MAP sensor onto the S&B MAP Sensor spacer. Then tighten down

Cookie Preferences

ck 10mm bolt holding  
the MAP Sensor to the spacer.



## STEP 4:

Take the provided 5mm Allen Bolt and use this to secure the S&B Map Sensor to the manifold.

Once done, go ahead and torque both the allen and hex head bolts to 60in. lbs.

## STEP 5:

Next, go ahead and plug in the MAP Sensor to the OEM wire harness using the

Cookie Preferences d extension harness  
within this kit.

## STEP 5:

The installation is now  
complete.

Please verify that all  
connection points are tight  
and secure.

Cookie Preferences