

Cookie Preferences

RS OVER \$98 (EXCLUSIONS APPLY)



SHOP CATEGORIES

WHY S&amp;B

SHOP BY VEHICLE



0

# INSTALL INSTRUCTIONS FOR 75-2503

PRINT

## BEFORE YOU START

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.
- Note: This intake kit may not fit with the following Aftermarket Parts installed: Body Lift or Lowering Kit, Custom Hood, Throttle Body Spacer / Upgrade

## REQUIRED TOOLS

- 2 7/16" Wrenches or Sockets
- 5/16" Nut Driver or Socket
- 5/16" Drill & Drill Bit

## Qty Parts List

1	5/8" x 25" Hose
1	Duel Flange Adapter
1	CARB Sticker
1	Instruction Sheet
1	#8 Hose Clamp
2	#48 Hose Clamps

## Qty Parts List (continued)

1	Angled Bracket
3	1/4"-20 x 3/4" Hex Head Screw
7	1/4" Washers
3	1/4"-20 Nylock Nuts
1	1/4"-20 Hex Head Screws
1	5/8" x 5/8" Coupling Hose
1	Air Filter

Hi. Need any help?

[Cookie Preferences](#)

## STEP 1

With the engine off,  
disconnect the negative  
battery cable.

**IMPORTANT: Failure to  
disconnect the battery for a  
minimum of 2 hours may  
cause the Check Engine  
Light to illuminate upon  
completion of the  
installation or subsequent  
operation.**

**DO NOT SKIP THIS STEP!**



## STEP 2

Unclamp intake hoses from  
the airbox.



[Cookie Preferences](#)

## STEP 3

Unbolt the airbox.



## STEP 4

Remove vent hose from airbox and valve cover.

## STEP 5

Remove airbox.

[Cookie Preferences](#)

## STEP 6

Install the “L” bracket to the end of the filter as shown.

## STEP 7

Install adapter assembly to filter.

[Cookie Preferences](#)

## STEP 8

Position assembly in vehicle  
and mark locations for drilling  
as shown in #8 Image 1 and  
#8 Image 2.

## STEP 8 IMAGE 2

[Cookie Preferences](#)

## STEP 9

Drill 5/16" holes where marked.

## STEP 10

Install using the hardware provided in this kit.

[Cookie Preferences](#)

## STEP 11

Measure vent hose provided in this kit (or the OEM hose).

## STEP 12

Cut the hose to the proper length. Insert the supplied 5/8" Hose Mender into the hose and secure the other end of the hose mender into the small middle inlet of the air filter. Then tighten the provided #8 Hose clamp.

## STEP 13

Reconnect the negative battery cable and check all of

[Cookie Preferences](#)

al assembly  
connections to ensure that all  
connections are tight.