

Cookie Preferences

OVER \$98 (EXCLUSIONS APPLY)



SHOP CATEGORIES

WHY S&B

SHOP BY VEHICLE



0

INSTALL INSTRUCTIONS FOR 75-5091

PRINT

BEFORE YOU START

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.
- Note: This intake kit may not fit with the following Aftermarket Parts installed: Body Lift or Lowering Kit Custom Hood, Throttle Body Spacer / Upgrade

REQUIRED TOOLS

- 10mm Wrench & Socket
- T-20 Security Torx Wrench (Supplied w/ Kit)
- 5/16" Nut Driver or Flat Blade Screwdriver
- Phillips Screwdriver



Hi. Need any help?



Cookie Preferences



Cookie Preferences

DESCRIPTION			P/N	ITEM	QTY.	DESCRIPTION	P/N
A	1	INTAKE TUBE	AI1265-00	O	3	WASHER, FLAT, M6	AI1535-00
B	1	INTAKE BOX	AI1241B-00	P	4	SCREW, TRUSS, 1/4-20	AI1684-00
C	1	CLEAR LID	AI1716-00	Q	1	FILTER MINDER GROMMET	AI1563-00
D	1	LID SEAL	AI1766-04	R	1	MAF PLATE	AI1822-00
E	1	COUPLER	AI1354C-00	S	1	MAF GASKET	AI1823-00
F	1	AIR FILTER	KF-1035	T	1	GROMMET PLUG	AI1705-00
G	1	BOX SEAL	AI1717C-00	U	2	HOSE CLAMP, #72	AG1009-00
H	1	FENDER SEAL	AI1829C-00	V	1	BOLT, HEX, M6 X 30mm	AI1414-00
I	1	BOX PLUG	AI1718C-00	W	3	SPACER GROMMET	AI2051-00
J	—	FILTER MINDER (NOT INCLUDED WITH THE KIT)					
K	1	HOSECLAMP, #80	AG-1010-00				
L	2	SCREW, PAN HEAD, 8-32	AI1837-00				
M	4	RUBBER WASHER	AI1571-00				
N	2	BOLT, HEX, M6 X 25mm	AI1415-00				

[Cookie Preferences](#)

STEP 1

With the ignition switched off and the parking brake set, disconnect the negative battery cables on both batteries.

IMPORTANT: Failure to disconnect the battery for a minimum of 2 hours may cause the Check Engine Light to illuminate upon completion of the installation or subsequent operation. **DO NOT SKIP THIS STEP!**



STEP 2

Disconnect the MAF sensor harness.



STEP 3

Cookie Preferences

th hose clamps and remove the stock intake tube from the vehicle.



STEP 4

Pull up on the stock airbox to release the prongs from the two rubber grommets on stock airbox tray.

STEP 5

Remove the four bolts on the stock airbox tray and remove the tray from the vehicle. Be sure to save the speed clips underneath. They will be reused to install the Intake Box (B) in Step 9.

[Cookie Preferences](#)

STEP 6

Insert the Fender Seal (**H**)
onto the Intake Box (**B**).

STEP 7

Insert the Tube Seal (**G**) onto
the Intake Box (**B**).

[Cookie Preferences](#)

STEP 8

Place the M6 Bolts (N & V) and Washers (O) through the mounting holes on the Intake Box (B) then press the Spacer Grommet (W) onto the bolts.

Note which M6 bolts goes where. The two mounting holes closest to the engine uses the 25mm and the closest to the fender uses the 30mm.

STEP 9

Install the Intake Box (B) into the truck. Align the bolts with the mounting points and tighten.

[Cookie Preferences](#)

STEP 10

Determine whether or not you want to install the Box Plug (I).

STEP 11

Remove the sensor from the stock intake tube. Use the provided MAF Gasket (S), MAF Mount (R), and Screws (L) to install the MAF sensor into the Intake Tube (A).

STEP 12

If you want to reuse the stock filter minder, insert the provided Filter Minder

Cookie Preferences (Q) into the Intake Tube (A). If not, skip to Step 13.

STEP 13

Insert the filter minder into the grommet.

[Cookie Preferences](#)

STEP 14

Install the Grommet Plug (T)
into the Intake Tube (A).

STEP 15

Insert the Air Filter (F) into
the Intake Box (B).

STEP 16

Slide the Coupler (E) and two
#72 Hose Clamp (U) onto the
Intake Tube (A). Tighten the
hose clamp closest to the
tube. Leave the other end
loose.

[Cookie Preferences](#)

STEP 17

Insert the Intake Tube (A) first into the Intake Box (B) and then slide the other end of the Coupler (E) onto the turbo mouthpiece. Tighten the #72 Hose Clamp (U) on the turbo mouthpiece.

[Cookie Preferences](#)

STEP 17 (IMAGE 2)

STEP 18

Slide the Air Filter (F) onto the Intake Tube (A) and tighten the #80 Hose Clamp (K).

STOP! READ THIS BEFORE CONTINUING THE INSTALL

If your kit came with our new snap-in lid design, please proceed to **STEP 22** to install your snap-in lid. If your lid is the traditional screw in lid,

[Cookie Preferences](#)

ceed to the next

step.

STEP 19

Press the Lid Seal (D) into the grooves on the Intake Box (B).

STEP 20

Remove the protective covering from the Clear Lid (C).

[Cookie Preferences](#)

STEP 21

Place the Clear Lid (C) on top of the Intake Box (B) and secure the lid using the four provided Lid Screw (P) and Rubber Washer (M).

[Go To Step 25](#)

STEP 22

For Snap-In Lids Only

Remove the protective covering from the Clear Lid.

STEP 23

For Snap-In Lids Only

Cookie Preferences

cone lid seal
around the perimeter of the
clear lid. It should be a snug
fit.

STEP 24

For Snap-In Lids Only

The notch on the lid and the
tab of the lid seal should
mate in the same corner.

STEP 25

Reconnect the MAF sensor
harness.

[Cookie Preferences](#)

STEP 26

Reconnect the negative terminal on both batteries.

Inspect your installation, make sure the kit is properly positioned and all fasteners are secure. Affix the ID label near the intake kit. The installation is now complete.

Cookie Preferences