

Cookie Preferences

OVER \$98 (EXCLUSIONS APPLY)



SHOP CATEGORIES

WHY S&B

SHOP BY VEHICLE



0

INSTALL INSTRUCTIONS FOR 75-5102

PRINT

BEFORE YOU START

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.
- Note: This intake kit may not fit with the following Aftermarket Parts installed: Trucks with Remote Start option, Body Lift or Lowering Kit, Custom Hood, Throttle Body Spacer/ Upgrade
- Install Video can be found [HERE](https://youtu.be/ymy3RnL6Vp8) <https://youtu.be/ymy3RnL6Vp8>

REQUIRED TOOLS

- 8mm, 10mm Socket and Wrench
- T20 Safety Torx
- Phillips Screwdriver



Hi. Need any help?



Cookie Preferences



ITEM	QTY.	DESCRIPTION	P/N	ITEM	QTY.	DESCRIPTION	P/N
A	1	INTAKE BOX	AL1241B-00	L	4	WASHER, RUBBER	AI1571-00
B	1	CLEAR LID	AI1716-00	M	2	SCREW, HEX, M6X1.00X25	AI1415-00
C	1	LID SEAL	AI1766-04	N	2	WASHER, M6	AI1535-00
D	1	AIR FILTER	KF-1035	O	4	SCREW, TRUSS, 1/4-20	AI1684-00
E	1	TUBE SEAL	AI1717C-01	P	1	FILTER MINDER GROMMET	AI1563-00
F	1	FENDER SEAL	AI1723C-00	Q	1	MAF PLATE	AI1722-00
G	1	AIR BOX PLUG	AI1778C-00	R	1	MAF GASKET	AI1777-00
H	1	INTAKE TUBE	AL1285-00	S	1	FILTER MINDER PLUG	AI1705-00
I	1	HOSECLAMP, #80	AG1010-00	T	1	COUPLER	AI1321C-01
J	2	HOSECLAMP, #64	AG1008-00				
K	2	SCREW, PHILLIPS, 8-32X3/4	AI1837-00				

[Cookie Preferences](#)

STEP 1

With the ignition switched off and the parking brake set, disconnect the negative battery cable on both batteries.

IMPORTANT: Failure to disconnect the battery for a minimum of 2 hours may cause the Check Engine Light to illuminate upon completion of the installation or subsequent operation. **DO NOT SKIP THIS STEP!**



STEP 2

Disconnect the MAF sensor harness.



[Cookie Preferences](#)

STEP 3

Remove the stock intake tube from the vehicle. Loosen the hose clamp at the turbo and stock intake box with a 5/16 Nut Driver or Flat Blade Screwdriver.



STEP 4

Remove the stock intake box by lifting up to unseat the two prongs from the airbox tray underneath.

STEP 5

Remove the five screws securing the factory airbox

[Cookie Preferences](#)10mm Socket or
Wrench.

STEP 6A

If you haven't done so already, remove the stock foil from the inner fender. This will allow for additional airflow with our kit.

[Cookie Preferences](#)

STEP 6B

Continue from 6a.

STEP 7

Install the Tube Seal (E) onto the Intake Box (A).

STEP 8

Install the Fender Seal (F) onto the Intake Box (A).

[Cookie Preferences](#)

STEP 9

Carefully remove the MAF sensor from the stock intake tube with a T20 Safety Torx. Use the provided Foam Gasket (R), MAF Plate (Q), and 8-32 Screws (K) to install the MAF sensor onto the Intake Tube (H) with a Screwdriver. The MAF sensor should be installed in the same orientation as shown below.

Note: The MAF connector should be facing the coolant reservoir when installed in the vehicle.

STEP 9 (IMAGE 2)

[Cookie Preferences](#)

STEP 10

Slide the Coupler (T) and two #72 Hose Clamps (J) onto the Intake Tube (H). Tighten the hose clamp closest to the tube. Leave the other end loose.

STEP 11

Decide whether or not you want to reuse the stock filter minder. Insert the Filter Minder Plug (S) into the Air Tube (H) if you decide to leave the stock filter minder out, otherwise, insert the Filter Minder Grommet (P) with the filter minder.

[Cookie Preferences](#)

STEP 11 (IMAGE 2)

STEP 12

Install the Airbox (A) into the vehicle. Secure the airbox using the provided M6 Screws (M) and Washers (N).

[Cookie Preferences](#)

STEP 13

Decide to install or leave out the Air Box Plug (G).

STEP 14

Place the Air Filter (D) into the Air Box (A) with Hose Clamp #80 (I). Do not tighten the hose clamp.

STEP 15

Insert the Air Tube (H) first into the Airbox (A) and then slide the other end of the Coupler (T) onto the turbo mouthpiece. Tighten the #72 Hose Clamp (M) at the turbo.

[Cookie Preferences](#)

STEP 16

Slide the Air Filter (D) onto the Air Tube (H) and tighten the #80 Hose Clamp (I).

[Cookie Preferences](#)

STEP 17

Remove the protective covering from the Clear Lid.

STEP 18

Stretch silicone lid seal around the perimeter of the clear lid. It should be a snug fit.

STEP 19

The notch on the lid and the tab of the lid seal should mate in the same corner.

[Cookie Preferences](#)

STEP 20

Reconnect the MAF sensor harness.

STEP 21

Reconnect the negative terminal on both batteries.

Inspect your installation, make sure the kit is properly positioned and all fasteners are secure. Affix the CARB and ID label near the intake kit. The installation is now complete.

Cookie Preferences