

Cookie Preferences

OVER \$98 (EXCLUSIONS APPLY)



SHOP CATEGORIES

WHY S&B

SHOP BY VEHICLE



INSTALL INSTRUCTIONS FOR 75-5175

PRINT

BEFORE YOU START

This intake kit may not fit with the following Aftermarket Parts installed:

Body Lift or Lowering Kit

Custom Hood

Throttle Body Spacer / Upgrade

REQUIRED TOOLS

- 8mm, 10mm, 11mm Wrench/Socket
- 16mm Wrench
- T20 Torx (Supplied)
- Phillips Screwdriver
- Flat Blade Screwdriver

Please read the entire product guide before proceeding.

Ensure all parts are present.

If you are missing any of the components, call our customer support at (909) 947-0015.

Do not work on your vehicle while the engine is hot.


Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.



Hi. Need any help?



Cookie Preferences



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
A	AI1758C-00	Front Inlet	1
B	KF-1095A	F150 Raptor R Filter Base : AI2878C-00 Top : AI2879C-00	1
C	AI2877C-00	F150 Raptor R Coupler	1
D	AI1423-00	AL1423-00	1
E	AI1423B-00	F150 Raptor R Box	1
F	AI1763-00	Plastic Rivet, 11/16 dia head, 1/4 dia x 7/8 long stem	2
G	AI1762-00	Rivet, Interlocking Shank, 1/4" dia x .50-.81" Grip, Blk Nylon	8
H	AI2875C-00	F150 Raptor R Silicone Box Seal	1
I	AI1563-00	Grommet, 1/2" ID x 1-1/16" OD, 7/16" Thk, 3/16" Panel	1
J	AI2876C-00	Snap-in Lid Seal	1
K	AI2874-00	F150 Raptor R Clear Lid	1
L	AI1948C-00	IAT Sensor Adapter, Silicone	1
M	AI3319-00	QUICK DISCONNECT	1
N	AI1857-00	Barbed hose fitting, 1/8" NPT x 3/16"	1
O	AG1018-00	Hose Clamp, #64	2
P	AG1030-00	hose clamp, #12	1
Q	AI1969-00	IAT Sensor Harness Extension, 14" Long	1
R	AI2936-00	Disconnect Tool, 5/8" Quick Connect Fitting	2
S	AI2296-00	Bushing, Shoulder, .40 ID x .50" OD, 1.06" Flange OD, .43" Long, AI	1
T	AI1750-00	Cable Tie, 6" Long	3
U	AI2355-00	CCV Insert	1

STEP 1

With the ignition switched off and the parking brake set, disconnect the negative battery cable on the driver's side.

IMPORTANT: Failure to disconnect the battery for a minimum of 2 hours may cause the Check Engine Light to illuminate upon completion

Cookie Preferences **Installation or subsequent operation. DO NOT SKIP THIS STEP!**

STEP 2

Remove the push rivets on the scoop with a flathead.



STEP 3

Disconnect the IAT sensor and the two Christmas trees connecting the harness to the airbox.



[Cookie Preferences](#)

STEP 3B

STEP 4

Loosen the hose clamp at the throttle body.

STEP 5

[Cookie Preferences](#)

the push on barb located near the throttle body.

STEP 6

Disconnect the permanent Ford quick connect using the provided tools. For clarification on removing, please watch our youtube video starting at 2:15.

<https://www.youtube.com/watch?v=w31qbJunz6Y>

[Cookie Preferences](#)

STEP 7

Remove the screw holding the stock intake to the vehicle.

STEP 8

Remove the stock intake from the vehicle.

STEP 9

Remove the IAT sensor from the stock intake. To remove, use a screwdriver to pry under the lock as shown in the picture, then twist counterclockwise.

[Cookie Preferences](#)

STEP 10

Clip in the IAT extension harness, then zip tie the harness to the side on the engine bay as shown in the picture.

[Cookie Preferences](#)

STEP 10B

STEP 11

Install the IAT grommet onto the S&B intake tube.

[Cookie Preferences](#)

STEP 12

Thread the small insert into the S&B intake tube. The insert is NPT so there will be some thread showing.

STEP 13

Install the bigger fitting into the tube. The insert is NPT so there will be some thread showing.

STEP 14

Unwrap the S&B filter and get it snapped into the airbox.

[Cookie Preferences](#)

STEP 15

Install the grommet and washer onto the S&B airbox.

[Cookie Preferences](#)

STEP 16

Install the scoop onto the S&B airbox using the provided push rivets.

STEP 17

Install the OEM IAT sensor into the S&B intake tube. Make sure the tab goes over the ramp as seen in the picture.

STEP 18

Cookie Preferences

S&B tube is fully assembled, install the tube into the filter. Then install the hose clamp and tighten down (not all the way).

STEP 19

Install the coupler and hose clamps onto the throttle body.

STEP 20

Drop the assembled airbox into the vehicle and install it onto the coupler at the throttle body. Then fully tighten down all the hose clamps.

[Cookie Preferences](#)

STEP 21

Reinstall the OEM bolt and fender washer. Then fully tighten down.

STEP 22

Re-install the hose onto the S&B barb located on the intake tube.

[Cookie Preferences](#)

STEP 23A

Orient the CCV tube insert,
the angled cut on the insert
should be facing the
supercharger

STEP 23B

Clip in the quick connect
extended CCV line and the
IAT sensor. Zip tie the IAT
sensor harness to the coolant
hose.

[Cookie Preferences](#)

STEP 24

Remove the protective cover on the S&B clear lid, then install the lid into the lid seal.

STEP 24 (IMAGE 2)

STEP 25

Snap the assembled S&B clear lid onto the airbox.

[Cookie Preferences](#)

STEP 26

Install the provided panel
poppers into the scoop.

Cookie Preferences