

Cookie Preferences

JVER \$98 (EXCLUSIONS APPLY)



SHOP CATEGORIES

WHY S&B

SHOP BY VEHICLE



0

INSTALL INSTRUCTIONS FOR 82-1004


[PRINT](#)

BEFORE YOU START

Thank you for purchasing your new S&B Filters Map Spacer. If at any time you need additional assistance with installation or have any other questions or comments, feel free to call our customer support team at 909-947-0015. **Approx. Install Time:** 15 min

REQUIRED TOOLS

- 7mm Wrench/Socket
- 8mm Wrench/Socket



| ITEM NO. | QTY. | PART NUMBER | DESCRIPTION |
|----------|------|-------------|--|
| A | 1 | AI2514-00 | AI2514-00,Black Anodize, Finished |
| B | 1 | AI2562-00 | O-Ring, Buna N,1.5mm x10.5 m Hi. Need any help? |
| C | 1 | AI2561-00 | Flange Bolt Stainless Steel, M5-0.8 x 10.. |



[Cookie Preferences](#)

STEP 1

Unplug the map sensor harness.



STEP 2

Remove the map sensor bolt using a 7mm wrench. Be careful not to drop this bolt in your engine bay. Access is limited on the 2017-2019 trucks so the shorter the wrench the better.



STEP 3

Remove the map sensor from the manifold. Pull up and

Cookie Preferences the spacer to get it free of the manifold.



STEP 4

Install the provided O-ring onto the S&B Map sensor spacer and install the spacer into the manifold. Make sure the bolt hole is lined up with the threaded insert in the manifold.

STEP 5

Install the map sensor with the original o ring into the S&B spacer. Again, make sure the bolt hole is lined up with both the hole in the spacer and the threaded insert in the manifold.

[Cookie Preferences](#)

STEP 6

Apply thread locker to the new bolt included with the S&B kit.

[Cookie Preferences](#)

STEP 7

Thread the bolt in as far as possible by hand and then use a 8mm wrench to snug it up and complete the last few rotations. Be careful not to overtighten the bolt.

STEP 8

Reconnect the map sensor harness.

Cookie Preferences