



SHOP BY VEHICLE



CONTACT & SUPPORT



0

## CONTACT US



### S&B AI AGENT

(Order Status, Knowledge Base, & more)



**EMAIL** customerservice@sbfilters.com



### TEXT

**(909) 947-0015**



### CALL

**(909) 947-0015**

Est. Wait: < 1 min

## BEFORE YOU START

**Kit may not fit with the following Aftermarket Parts installed:**

Aftermarket Front Bumper

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.

\*Click [here](#) to **watch** the install instead!

## REQUIRED TOOLS

- Flathead Screwdriver
- 8mm Shallow Socket
- 8mm Deep Socket
- Various Extensions
- 18mm Shallow Socket
- 18mm Wrench or Adjustable Crescent Wrench
- Electric Ratchet
- Wire Cutters

Cookie Preferences

## BEFORE YOU BEGIN

Place the vehicle in park, engage the Parking Brake, and we recommend using wheel chocks.



## STEP 1

If you haven't done so already, go ahead and remove the S&B valance from the cardboard and allow it to extend fully while you're removing the factory valance.



## STEP 2

Using an **8mm Socket** and **Electric Ratchet**, it's time to remove the bolts holding

Cookie Preferences

the factory valance to the front bumper.

***Important:*** The middle point will be accessible from the bottom, whereas the end bolts will have to be accessed from the top side.

## **STEP 2B**

## **STEP 3**

Remove and transfer the OEM clip nuts from the factory valance to the S&B Low Profile Valance. Make sure to match the factory location of each clip nut to the S&B Valance.

[Cookie Preferences](#)

There will be **(3)** Clip Nuts on either end and they will be spaced out as seen in this image.

## STEP 4

Now, go ahead and unbolt those **(2)** brackets hanging down from frame rails. To do this, you'll need a ratchet and **18mm Shallow Socket** and **18mm Wrench**.

There will be **(4)** nuts to undo on both brackets.

## STEP 5

Now, go ahead and install the S&B Low-Profile Valance onto

Cookie Preferences  imper using an **8mm Socket** and **Ratchet**.

## **STEP 6**

Verify that all bolts are tight and secure in their position and that no clip nut got skipped.

Your install is now complete.

[Cookie Preferences](#)

Cookie Preferences