



SHOP BY VEHICLE



CONTACT & SUPPORT



0

## CONTACT US



### S&B AI AGENT

(Order Status, Knowledge Base, & more)



**EMAIL** customerservice@sbfilters.com



### TEXT

**(909) 947-0015**



### CALL

**(909) 947-0015**

Est. Wait: < 1 min

## BEFORE YOU START

**Kit may not fit with the following Aftermarket Part(s) installed:**

Custom or Aftermarket Bumper

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.

## REQUIRED TOOLS

- 8mm Socket
- 18mm Deep Socket
- Electric or Mechanical Ratchet
- Zip-Ties
- Wire Cutters
- Body Panel Removal Tool

## STEP 1

Using an **8mm** Socket and Electric Ratchet, go ahead and work your way down the underside of the factory

Cookie Preferences



## STEP 2

Next, remove the 5x clips (1 on each side of valance, 3 in the middle) holding the wiring harness. This can be done using a body panel removal tool.



### STEP 3

Then zip-tie the harness up into the front bumper.



### STEP 4A

Now it's time to remove the 2x factory bumper brackets using an **18mm** deep socket.

## **STEP 4B**

Cookie Preferences

## STEP 5

Using an **8mm** socket, go ahead and bolt the S&B Low-Profile Valance into the factory position using the OEM hardware.

## STEP 6

Verify that all the bolts are tight and secure.

Your install is complete.

Cookie Preferences