

07.27.11

## AMP RESEARCH POWERSTEP™ - DROP DISTANCE

How far does the step drop when deployed? To give an accurate answer, we measured the distance from the top of the doorsill step plate to the top stepping surface of the deployed running board.

Vehicle	Measurement: Top of the doorsill plate to top surface of deployed running board.
Chevy Silverado GMT 800, 1999-2007 Classic	<b>X = 13"</b>
Chevy Silverado GMT 900, 2007+	<b>X = 13 ½"</b>
GM SUVs Suburban/Tahoe/Escalade	<b>X = 12 ¾"</b>
Hummer H2	<b>X =</b>
Hummer H3	<b>X = 13 ½"</b>
Ford Super Duty	<b>X = 13 ½"</b>
Ford F-150	<b>X = 12"</b>
Jeep Wrangler (JK)	<b>X = 12 ½"</b>
Ram	<b>X = 13 ¾"</b>
Nissan Titan	<b>X = 11"</b>
Toyota Tacoma	<b>X = 11"</b>
Toyota Tundra	<b>X = 11 ½"</b>

