



PART NUMBER		PART DESCRIPTION
97000064RRH	10	KICK PANEL OUTER REAR - RH
97000060RRH	11	PANEL, TRIM, "B" PILLAR, LOWER - RH
97000077R	12	PANEL, KICK, OUTER FRONT, RH
97000062R	13	PANEL, KICK, OUTER CENTER, RH
97000079R	14	PANEL, KICK, INTER FRONT, RH
97000076R	15	PANEL, KICK, INNER FRONT, LH
97000061R	16	PANEL, KICK, OUTER CENTER, LH
97000047R	17	PANEL, TRIM, REAR
97000078R	18	PANEL, KICK, OUTER FRONT, LH
97000080R	19	PANEL, KICK, INNER REAR, RH
97000081R	20	PANEL, KICK, INNER REAR, LH
97000063R	21	KICK PANEL OUTER REAR - LH
97000059R	22	PANEL, TRIM, "B" PILLAR, LOWER - LH

INSTRUMENT PANEL AND DRIVER'S CLOSEOUT - RAW MATERIAL




PART NUMBER		PART DESCRIPTION
97000082R	1	PANEL, INSTRUMENT PANEL
97000055R	2	PANEL, INSTRUMENT PANEL CLOSEOUT


UPPER CRASH PAD - RAW MATERIAL



PART NUMBER		PART DESCRIPTION
97000051R	4	UPPER CRASH PAD - TOP
97000048R	5	UPPER CRASH PAD - BOTTOM



PART NUMBER		PART DESCRIPTION
97000045R	6	PANEL ASSEMBLY, UPPER CONSOLE UPPER TRIM
97000057R	7	COVER, MAP POCKET



PART NUMBER		PART DESCRIPTION
97000065R	8	CRASH PAD, RH
97000054R	9	CENTER DASH

