


INSTALLATION INSTRUCTIONS
Gen 3 Portal Gear Hubs
Can-Am Maverick X3

Item	Description
A	Rotor x 4
B	Left Gear Box x 2
C	Right Gear Box x 2
D	Gasket x 4
E	Cap x 4
F	Front Recessed Nut x 2
R	Rear Recessed Nut x 2



(Kit Contents continue on following pages)

WHEN FILLING GEAR BOX USE ONLY 80W-90 GEAR OIL. USING GREASE WILL CAUSE FAILURE OF GEARS AND BEARINGS. USING GREASE WILL VOID THE WARRANTY.

Need help with your installation?


 sales@superatv.com
 www.superatv.com

 1-855-743-3427
  8:00am - 9:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday


Read instructions and view illustrations before beginning.

Thank You
For Choosing
SUPERATV.COM[®]










(Kit Contents continued)



Item	Description
G	Caliper Mounting Bracket A x 2
H	Left Spindle
J	Right Spindle
K	Right Bearing Carrier
L	Left Bearing Carrier
M	Left Steering Arm
N	Right Steering Arm
P	Caliper Mounting Bracket B x 2



Front Hardware Kit





Threadlock, 2mL




Machines with SuperATV Heavy Duty Tie Rod Ends must use provided hardware shown when securing to Steering Arms.



Rear Hardware Kit



Castle Nut



(disregard any remaining hardware)

Rear Brake Lines

Location	Length (Approx)
To Calipers	96"
T-Fitting to Master Cylinder	28"

2x - Brake Line Clip



PGH-7-72-302 models use BL062 (68" long) for T-Fitting to Master Cylinder



T-Fitting



Read ALL instructions prior to operating Portal Gear Hubs. Injury to personnel, portal gear hub, and/or machine failure may be caused by improper installation, maintenance or operation.

- It is dangerous to get under a jacked-up vehicle. The vehicle could slip off the jack and fall on you. You could be crushed. Never place any part of your body under a vehicle that is on a jack. Never start or run the engine while the vehicle is on a jack. If you need to get under a raised vehicle, take it to a service center where it can be raised on a lift.
- Hot oil can cause severe burns. Use extreme care when removing lubrication plugs and when working close to a unit that has been in operation.
- Check lube level between scheduled lube changes to insure that proper lube level is maintained. Inspect the tightness of mounting bolts, excessive heating, or any unusual noise or vibration.
- Serious personal injury may occur as a result of improperly performed maintenance, adjustments or repairs.
- Always be extremely careful when working on the portal gear hub. Always follow commonly accepted safety practices and general common sense. Never risk personal injury.
- Do not operate the portal gear hub without proper lube and correct amount.

For safe operation and to maintain the unit warranty, when changing a provided fastener for any reason, it becomes the responsibility of the person making the change to properly account for fastener grade, thread engagement, load, tightening torque and the means of torque retention.

- Mounting bolts should be periodically checked to ensure that the unit is firmly anchored for proper operation.
- These instructions are not intended to cover all details or variations in equipment, nor provide for every possible contingency to be met in connection with selection, installation, operation, and maintenance.


Should further information be desired or should particular problems arise which are not covered sufficiently for the Buyer's purpose, the matter should be referred to SuperATV®.

In the event of the resale of any of the goods, in whatever form, Resellers/Buyers will include the following language in a conspicuous place and in a conspicuous manner in a written agreement covering such sale:

The manufacturer makes no warranties or representations, express or implied, by operation of law or otherwise, as to the merchantability or fitness for a particular purpose of the goods sold hereunder. Buyer acknowledges that it alone has determined that the goods purchased hereunder will suitably meet the requirements of their intended use. In no event will the manufacturer be liable for consequential, incidental or other damages. Even if the repair or replacement remedy shall be deemed to have failed of its essential purpose under Section 2-719 of the Uniform Commercial Code, the manufacturer shall have no liability to Buyer for consequential damages.

Resellers/Buyers agree to also include this entire document including the danger, warnings and cautions above in a conspicuous place and in a conspicuous manner in writing to instruct users on the safe usage of the product.

 **When installing or removing hardware shown DO NOT USE IMPACT WRENCH.**
Torque to 60 ft/lbs MAX



Install provided Studs into Rotors (A):

- See "Wheel Hub Bolt Patterns".
- Note machines bolt pattern and lug size.
- Set Rotors (A) aside when complete.



Use a brass Punch and hammer when installing Studs




Use spacers of some sort when installing Studs.

Sockets work well as spacers


Wheel Hub Bolt Patterns

- A - - - -
- B - - - -
- C - - - -
- D - - - -



Pattern	Machine	Diameter
A	Polaris	156mm
B	Can-Am/Teryx4	137mm
C	Arctic Cat	115mm
D	Honda/Yamaha	110mm

Front Components Removal: *Keep all components removed from machine.*



Rear Components Removal: *Keep all components removed from machine.*



Remove:

- Control Links from Arms and Knuckles
- Brake Lines from Arms and Calipers
- Axle Nuts and Pins
- Hubs / Knuckles / Disc / Calipers

(passenger side)

- Remove Retaining Rings and Radial Joints.




SuperATV strongly recommends purchasing new Retaining Rings and Radial Joints.

Front: do not tighten hardware completely unless noted.

- Install Spindle, R (J) to A-Arms with stock hardware.




- Secure Steering Arm, R (N) to Spindle, R (J) with hardware shown.
- Secure Tie Rod End to Steering Arm, R (N) with stock hardware.




Front continued:

- Install Right Gear Box (C) to Right Spindle (J) with hardware shown.
- Secure Caliper Mounting Bracket to Right Gear Box (C) with hardware shown.
- Secure Caliper Mounting Bracket **A** (G) with hardware shown.
- Secure Caliper Mounting Bracket **B** (P) to passenger side.



Front continued:

- Secure stock Axle with Front Recessed Nut (F); use thread locker.
- Secure Gasket (D) and Cap (E) with hardware shown.
- Secure Rotor (A) to Gear Box Axle Shaft with hardware shown.



- Torque to minimum 300 Ft/Lbs.
- Continue tightening until Cotter Pin can be installed.

Tighten hardware completely and repeat steps for opposite side.

Front continued:

- Reroute Brake Line UNDER Frame as shown.





- Front Calipers must be switched; passenger side to driver side. Bleeder Valves must face up.
- Secure Calipers to Caliper Mounting Brackets (G)(P) with stock hardware.



Front continued:


- Secure stock Brake Line to Right Steering Arm (N) and A-Arm with stock Clips and hardware shown.



- Repeat steps for opposite side.

Rear: *do not tighten hardware completely unless noted.*

- Install stock or new Retaining Rings and Radial Joints into Bearing Carriers (K)(L).
- Use Heim Tool and a hammer when installing.




- Install Right Bearing Carrier (K) to Rear Arm and Control Links with stock hardware.




Rear continued:

- Install Right Gear Box (C) to Right Bearing Carrier (K) with hardware shown.
- Secure Caliper Mounting Bracket B (P) to passenger side.
- Secure Caliper Mounting Bracket A (G) with hardware shown.
- Repeat for opposite side and tighten all hardware completely.



Rear continued:

- Secure stock Axle with Rear Recessed Nut (R); use thread locker.
- Secure Gasket (D) and Cap (E) to Left Gear Box (B) with hardware shown.
- Secure Rotor (A) to Gear Box Axle Shaft with hardware shown.




- Torque to minimum 300 Ft/Lbs.
- Continue tightening until Cotter Pin can be installed.

Repeat steps for opposite side and tighten all hardware completely.

Rear continued:



- Rear Calipers must be switched; passenger side to driver side. Bleeder Valves must face up.
- Secure Calipers to Caliper Mounting Brackets with stock hardware.




- Tighten all hardware completely.
- Repeat steps for opposite side.

Rear Brake Lines:

Remove components shown on following pages.



Rear Brake Lines continued:




Rear Brake Lines continued:





- Pull Rear Brake Lines from machine.

- Install provided Brake Lines to Master Cylinder and provided T-Fitting.
- Secure provided T-Fitting to stock location with hardware shown. T-Fitting Spacer goes under T-Fitting.
- Reinstall components previously removed.




Rear Brake Lines continued:

- Install stock Brake Line Clips to new Brake Lines.
- Route Rear Brake Lines from T-Fitting to Calipers.
- Follow stock Brake Lines path.
- Ensure that no binding, rubbing, or interference can occur.
- Secure to Rear Arms with stock Brake Line Clips and hardware shown.
- Bleed system.



- Attach a hose to a funnel and fill each Gear Box (B-C) with 80W-90 Gear Oil.
- Fill up to fill hole.
- Install Drain Plug.



Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warranted if item was not installed properly, misused, or modified.


Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.


***Instructions for OPTIONAL Frame
Stiffener, Winch Mount, etc. included.***

***Disregard if only Portal Gear Hubs
are being installed.***

INSTALLATION INSTRUCTIONS
Frame Stiffener: for Can-Am Maverick X3




A



B




E




D

Item	Description
A	Top Support
B	Arm Support
D	Frame Support
E	Backing Plate




5x

M12-1.75 x 30mm Lg. FHCS




4x

M12-1.75 x 90mm Lg. Cross Drilled FHCS



13x

M12-1.75 Nylock Nut



2x

M12-1.75 x 100mm Lg. HHCS

Need help with your installation?



sales@superatv.com



www.superatv.com



1-855-743-3427



8:00am - 9:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

Thank You

For Choosing




Keep all components removed from machine.

- Remove hardware shown from Front Fascia.




- Remove Front Deflector.



- Remove stock Bulkhead from machine.



- Remove components shown from Front A-Arms.



Remove front Axles.

- Remove hardware shown from Shroud.




- If present, remove stock Lower Radiator Deflector from machine.





Remove A-Arms from machine.


- Remove Front Differential and hardware shown.



- Install Backing Plate (E) with hardware shown.



- Place Arm Support (B) onto Frame.




**BOTH LOWER A-ARMS MUST BE INSTALLED SIMUTANEOUSLY;
EXTRA HANDS ARE RECOMMENDED**




- Place Lower A-Arms onto previously installed hardware and into Arm Support (B).
- Slide Lower A-Arms and Arm Support (B) onto stock Studs.
- Secure A-Arms with hardware shown. SuperATV recommends Loc-Tite on Nuts when installing.
- Reinstall Differential.




- Install Frame Support (D) to Frame with hardware shown.




- Place Top Support (A) onto Frame Support (D).
- Install hardware shown into Backing Plate (E).



- Secure Top Support (A) to Frame Support (D) and Backing Plate (E) with hardware shown.



- Install Upper A-Arms onto hardware shown.
- Secure A-Arms with hardware shown. SuperATV recommends Loc-Tite on Nuts when installing.
- Reinstall necessary stock components and tighten all hardware completely.



Liability Statement

SuperATV's® products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV® and is not recommended. SuperATV's® products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV® to verify that they will work together.

Although SuperATV® has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV® urges operators and occupants to wear a helmet and appropriate riding gear at all times.


By purchasing and installing SuperATV® products, user agrees that should damages occur, SuperATV® will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV®, nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV®. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV® will warranty only parts provided by SuperATV®. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV®. SuperATV® parts and products are not warrantied if item was not installed properly, misused, or modified.





Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV® harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV® harmless from any violation thereof.

INSTALLATION INSTRUCTIONS
Winch Mount: for Can-Am Maverick X3



Winch not included; shown for illustration only.



**Use only if SuperATV Frame Stiffener is installed.*

Need help with your installation?

sales@superatv.com www.superatv.com

1-855-743-3427 8:00am - 9:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday

Read instructions and view illustrations before beginning.

*Thank You
 For Choosing*
SUPERATV.COM[®]

Liability Disclaimer

SupercATV[®] products are designed to be used on user's ATVs/UTVs under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SupercATV[®] and is not recommended. SupercATV[®] products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SupercATV[®] to verify that they will work together.

Although SupercATV[®] has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension lifts, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol or/and drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SupercATV[®] urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SupercATV[®] products, user agrees that should damages occur, SupercATV[®] will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SupercATV[®], nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SupercATV[®]. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SupercATV[®] will warranty only parts provided by SupercATV[®]. Any damage or problems with OEM bearings, bearings, seals, or other manufacturer's products will not be covered by SupercATV[®]. SupercATV[®] parts and products are not warranted if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATVs/UTVs may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, health laws, and ordinances. It is your responsibility to know the laws and how they apply to you.


The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agree to hold SupercATV[®] harmless from any damage resulting from failure to adhere to such specifications, warnings and/or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SupercATV[®] harmless from any violation thereof.

Keep all components removed from machine.

- Remove hardware shown from Front Fascia.



- Remove Front Deflector; will not be reinstalled.



- Remove stock Bulkhead from machine. Bulkhead will be replaced with Winch Mount.




- Install Winch Mount onto A-Arm bolts.
- Reinstall A-Arm nuts and tighten completely.




Skip this step if SuperATV Frame Stiffener is not installed.


- Secure Winch Mount to Frame Stiffener with hardware shown.




- Install Fairlead to Winch Mount.
- Fairlead and hardware included with Winch.
- Install Clip Nuts to Winch Mount.



- SuperATV 3500 Lb. Winch will require installation of Fairlead Adapter as shown.



- Install Winch to Winch Mount.
- Hardware included with Winch.



- Tighten all hardware completely.

RADIATOR SHROUD MUST BE REINSTALLED TO LOCATION SHOWN



- Secure Front Fascia to Winch Mount with hardware shown.

