

Cookie Preferences

RS OVER \$98 (EXCLUSIONS APPLY)



SHOP CATEGORIES

WHY S&B

SHOP BY VEHICLE



0

INSTALL INSTRUCTIONS FOR 75-5069

PRINT

BEFORE YOU START

- Please read the entire product guide before proceeding.
- Ensure all parts are present.
- If you are missing any of the components, call our customer support at (909) 947-0015.
- Do not work on your vehicle while the engine is hot.
- Make sure the engine is turned off and the vehicle is in Park or the Parking Brake is set.
- Note: This intake kit may not fit with the following Aftermarket Parts installed: Body Lift or Lowering Kit, Custom Hood, Throttle Body Spacer / Upgrade

REQUIRED TOOLS

- 8mm, 10mm, 13mm Wrench & Socket
- Pin Removal Tool or Flat Blade Screwdriver
- 7/16" Wrench and Socket
- 5/16" Nut Driver or Flat Blade Screwdriver
- Phillips Screwdriver
- 1 Set of Torx Wrenches & Allen Wrenches
- 1 Pair of Pliers or similar tool



Hi. Need any help?



Cookie Preferences



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	AI1664-01	Clear Lid	1
3	AI2531C-01	Snap-in Silicone Seal	1
3	KF-1060	S&B Filter	1
4	AI1224B-02	Air Box	1
5	AI1224-00	Intake Tube	1
6	AI1665C-00	Coupler (For 5.3L)	1
7	AI1542C-01	Coupler (For 6.2L)	1
8	AI1559C-00	Box Plug	1
9	AI1550C-00	Fender Seal	1
10	AG1018-00	Hose Clamp, #64	2
11	AG1035-00	Hose Clamp, #10	2
12	AG1009-00	Hose Clamp, #72	1
13	AI1368-00	Grommet	1
14	AI1637-01	Mat Gasket	1
15	AI1039-09	Silicone Hose	2
16	AI2110-00	Filter Support Bracket	1
17	AI1257-00	M6 Bolt	4
18	AI1535-00	M6 Washer	4
19	AI1209-01	Plate, Maf Sensor	1
20	AI1720-00	Screw 8-32 x 3/8"	4
21	AI1719-00	Screw 10-32 x 1/2"	2

STEP 1

With the ignition switched off and the parking brake set, disconnect the negative battery cable on the passenger's side.

IMPORTANT: Failure to disconnect the battery for a

Cookie Preferences m of 2 hours may cause the Check Engine Light to illuminate upon completion of the installation or subsequent operation. DO NOT SKIP THIS STEP!



STEP 2

The sensor must be removed from the factory intake cover using a Torx bit.



STEP 3

Once the sensor is removed, disconnect the sensor from the harness by pulling the **Red** tab out and pressing down on the release button while pulling out. Place the sensor in a safe location for later install.

[Cookie Preferences](#)

STEP 4

Use a nut driver to loosen the hose clamp on the factory airbox cover.

STEP 5

Once the hose clamp is loose, pull the tube to the right to remove from the factory airbox cover.

[Cookie Preferences](#)

STEP 6

Remove the factory hose
from the OE resonator box by
first pressing in the grey
button up on the bottom.

STEP 6 (IMAGE 2)

...Continue from Step 6.

[Cookie Preferences](#)

STEP 6 (IMAGE 3)

STEP 7

Loosen the hose clamp at the throttle body.

[Cookie Preferences](#)

STEP 8

Remove the resonator box off the throttle body and out of the vehicle.

STEP 9

Remove both crankcase hoses from each valve cover by pressing in the grey button then lift up.

STEP 10

Remove the top bolt from the front crossbar using a 10mm socket.

[Cookie Preferences](#)

STEP 11

Remove the 4 plastic push pins on the far left side of the front liner to gain access to the front crossbar. To remove the push pins use a flat blade screwdriver to pop out the top head and pull out.

STEP 12

Lift up on the liner and remove the lower bolt using a 10mm socket from the front crossbar. Remove from the vehicle, this part will be reinstalled later.

[Cookie Preferences](#)

STEP 13

Disconnect the clip securing the MAF harness to the airbox. Then remove the bottom portion of the factory airbox by pulling up and out.

STEP 14

Remove all four bolts from the factory mounting plate then remove the factory mounting plate from the vehicle.

[Cookie Preferences](#)

STEP 14 (IMAGE 2)

STEP 15

Install the Side Fender Seal (F) onto the Airbox (A) and press on firmly.

[Cookie Preferences](#)

STEP 16

Determine if you want to install the Box Plug (G) onto the Airbox (A) or leave it open. If the Box Plug is desired, simply press the Box Plug into the box opening until it snaps into place.

STEP 17

Insert the Grommet (X) onto the Filter Support Bracket (W) and place inside the Airbox (A).

STEP 18

[Cookie Preferences](#)

If you have vehicles equipped with HID headlights proceed to Step 19, otherwise continue with Step 18. Install the Airbox (A) and remember to properly align the fender seal to the side fender opening. Secure the airbox and Filter Support Bracket (W) with the M6 Bolts (L) and Washers (K). Make sure all fasteners are tightened. Go to Step 22.

STEP 18 (IMAGE 2)

STEP 19

If you have vehicles equipped with HID headlights there is an extra step that will be needed to install the Airbox (A) due to the headlights

[Cookie Preferences](#)

les out the back more so than the regular headlights. Use a 10mm to remove the two fasteners securing the coolant reservoir in the front and behind the battery. Set the fasteners aside they will be reused in Step 20. Set the coolant reservoir on top of the engine.

STEP 19 (IMAGE 2)

STEP 20

Install the Airbox (A) and remember to properly align the fender seal to the side fender opening.

[Cookie Preferences](#)

STEP 21

Before securing the Airbox (A) you will have to reinstall the coolant reservoir. Lift one side of the airbox slightly and slide the coolant reservoir into position. Reinstall the fasteners removed in Step 18 with a 10mm. Then secure the airbox and Filter Support Bracket (W) with the M6 Bolts (L) and Washers (K). Make sure all fasteners are tightened.

[Cookie Preferences](#)

STEP 21 (IMAGE 2)

STEP 22

Install the Air Filter (E) by pressing the filter tabs through the side of the Airbox (A). The filter should lock into place when the tabs are secured.

STEP 23

Install the larger side of the Coupler (C or D) onto the Air Tube (B) with the #72 and #64 Hose Clamps (U & T). Tighten the #72 Hose Clamp

Cookie Preferences Intake tube. The coupler used is dependent on the vehicle engine liter you have.

NOTE: (5.3L use AI1665C-00,
6.2L use AI1542C-00)

STEP 24

Use the provided Hardware (O) to install the MAF Plate (N) and Gasket (M) onto the Air Tube (B). The arrow on the plate should line up with the arrow on the tube.

STEP 25

Use the provided Hardware (P & Q) to install the MAF sensor onto the MAF Plate.

[Cookie Preferences](#)

STEP 26

Install the #64 Hose Clamp
(T) loosely over the Air Filter
(E) push the Intake Tube(B)
into the filter then slide the
intake tube and coupler onto
the throttle body. Once
positioned properly tighten
all hose clamps.

[Cookie Preferences](#)

STEP 26 (IMAGE 2)

STEP 27

Connect the MAF harness to the MAF sensor. Make sure the red locking latch is secure.

STEP 28

Use the provided Hose Clamps (V) and Crankcase Hoses (J) to install onto the valve cover 's intake tube. Once the hoses are secured to the Intake Tube, install onto the vehicle and tighten

Cookie Preferences with the provided Hose Clamps (V).

STEP 28 (IMAGE 2)

 **STOP! READ THIS
BEFORE CONTINUING
THE INSTALL.**

If your kit came with our new snap-in lid design, please proceed to STEP 31 to install your snap-in lid. If your lid is the traditional screw in lid, please proceed to the next step.

[Cookie Preferences](#)

STEP 29

Remove the protective covering on the Clear Lid (H) and install the Lid Bumper (I).

STEP 30

Install the Clear Lid (H) using the provided Hardware (R & S).

STEP 31

For Snap-In Lids Only

Cookie Preferences Remove the protective covering from the Clear Lid.

STEP 32

For Snap-In Lids Only

Stretch silicone lid seal around the perimeter of the clear lid. It should be a snug fit

STEP 32 (IMAGE 2)

For Snap-In Lids Only

The notch on the lid and the tab of the lid seal should mate in the same corner.

[Cookie Preferences](#)

STEP 33

Reinstall the front crossbar and push pins on the plastic liner.

STEP 34

Reconnect the negative terminal on both batteries. Inspect your installation, make sure the kit is properly positioned and all fasteners are secure. Affix the ID label near the intake kit. The installation is now complete.

Cookie Preferences