


INSTALLATION INSTRUCTIONS

6" Lift Kit: for Polaris Ranger[®] 1000

- A Press or Ball Joint tool is required to remove and install Ball Joints.

- Do not discard packaging until product has been successfully installed.





© 2019 SuperATV.com[®]. All Rights Reserved.


Rev IN-LK-P-RAN1K-6 / IN-LK-P-RAN1K-6-001 / IN-LK-P-RAN1K-6-002 12/5/2022

Thank You

For Choosing


(kit contents continued)

Item	Description
J	Z-Bend Tie Rod Kit
К	Sway Bar
L	Sway Bar Link x 2
М	Front Brace
N	Rear Shock Bracket x 2
Р	Front Shock Bracket x 2



IN-LK-P-RAN1K-6 / IN-LK-P-RAN1K-6-001 / IN-LK-P-RAN1K-6-002

DURING INSTALL DO NOT TIGHTEN HARDWARE COMPLETELY UNLESS NOTED.



Liability Statement

SuperATV's[®] products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV[®] and is not recommended. SuperATV's[®] products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV[®] to verify that they will work together.

Although SuperATV[®] has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV[®] urges operators and occupants to wear a helmet and appropriate riding gear at all times.

By purchasing and installing SuperATV[®] products, user agrees that should damages occur, SuperATV[®] will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV[®], nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV[®]. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV[®] will warranty only parts provided by SuperATV[®]. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV[®]. SuperATV[®] parts and products are not warrantied if item was not installed properly, misused, or modified.

Installing, adding, modifying, or fabricating any factory or aftermarket product to your ATV/UTV may violate certain local, state, and federal laws. Be advised that laws vary depending on town, city, county, state, etc. Use of certain products on public streets, roads, or highways may be in violation law. The Buyer is solely and exclusively legally and personally responsible for any violation of the law by the installation or use of the product. You must abide by all local, state, and federal laws, including but not limited to vehicle safety, traffic laws, and ordinances. It is your responsibility to know the laws and how they apply to you.

The Buyer is responsible to fully understand the capability and limitations of his/her vehicle according to manufacturer specifications, warnings and instructions and agrees to hold SuperATV[®] harmless from any damage resulting from failure to adhere to such specifications, warnings and/ or instructions. The Buyer is also responsible to obey all applicable federal, state, and local laws and ordinances when operating his/her vehicle while using this product, and the Buyer agrees to hold SuperATV[®] harmless from any violation thereof.

Front Components Removal: Keep all components removed from machine.




- Remove stock hardware shown from Differential.




PIVOT BLOCK SETTINGS

- Place new A-Arms onto a flat surface and verify dimension shown.
- Negative 1° camber setting is achieved when Pivot Blocks are set to this dimension.
- See last page for additional camber information.




Front A-Arms Prep:

- Install stock Ball Joints, Bushings, and Pivot Shafts.
- Install provided Fittings.
- Set aside.




Steering Stop Installation: Rack and Pinion shown off machine for clarity.

- Install Steering Stops onto Rack and Pinion Shafts.




Tie Rod Installation:

- Remove Jam Nuts from Ball and Sockets.
- Install Ball and Sockets to Rack and Pinion. Use Loctite.
 Install Boots to Rack and Pinion and secure with Wire Ties. Use a lubricant to ease installation.
 - · Reinstall Jam Nuts to Ball and Sockets
- Install Tie Rod Shafts to Ball and Sockets.
 - Install Tie Rod Ends to Tie Rod Shafts
- When installing to Hubs, secure Tie Rod Ends to same location as stock with hardware shown.




Front Brackets Installation:

- Install Front Shock Bracket (P) to stock Shock Mount with hardware shown.
- Repeat for opposite side. Tighten hardware completely.




Front Brackets Installation continued:

- Install Front Brace (M) to Front Shock Brackets (P) with hardware shown.




- Secure Shocks to Front Shock Brackets (P) with Shock Spacers and hardware shown.




FOR LK-P-RAN1K-6-002 KIT ONLY

- Slide Spacers under Differential and secure with provided hardware.
- Tighten all hardware completely.
- Install new Axles.




Front A-Arms Installation:

- Install Upper A-Arms to Frame with stock hardware. SuperATV recommends using Loc-Tite on Nuts.
- Install Lower A-Arms to Frame; Do not completely tighten Nuts on Lowers until all final adjustments have been completed.




Front A-Arms installation continued:

- Install Shocks to Upper A-Arms with hardware shown.
- Install Knuckles with stock hardware; **Do not completely tighten Nuts on Lowers until all final** adjustments have been completed.
- Secure Tie Rods to Knuckles; see page 7.
- Secure Sway Bar Links to Upper A-Arms with stock hardware.
- Install and secure provided Brake Lines with components shown.




Front A-Arms installation continued:

- Install and secure provided Brake Lines to Upper A-Arms with components shown.



Rear Components Removal: Keep all components removed from machine.



Polaris Ranger^{® XP} 1000 Muffler note:




To access A-Arm hardware, Muffler must be removed if located as shown.



PIVOT BLOCK SETTINGS

- Place new A-Arms onto a flat surface and verify dimension shown.
- Negative 1° camber setting is achieved when Pivot Blocks are set to this dimension.
- See last page for additional camber information.




*Leave Jam Nuts loose. Tighten after final adjustments have been made.

Rear A-Arms Prep:

- Install stock Bushings and Pivot Shafts.
 Install provided Fittings.
 Set aside. 90° Fitting 2x Left 2x (Straight Fitting

Rear Brackets Installation:

- Install Rear Shock Bracket (N) to stock Shock Mount with hardware shown; repeat for opposite side.




Rear A-Arms Installation:

- Install Upper A-Arms to Frame with stock hardware. SuperATV recommends using Loc-Tite on Nuts.
 Install Lower A-Arms to Frame; *Do not completely tighten Nuts on Lowers until all final*
- adjustments have been completed.
- Install new Axles.



Rear A-Arms installation:


- Install Shocks to Rear Shock Brackets (N) and Lower A-Arms with hardware shown.
- Install Knuckles with stock hardware; **Do not completely tighten Nuts on Lowers until all final** adjustments have been completed.



Arm-to-Shock hardware must be ortented as shown

Rear continued:


- Install Sway Bar (K) to Frame with stock components.
- Install Sway Bar Links (L) to Sway Bar (K) with hardware shown.
- Secure Sway Bar Links (L) to Rear Upper A-Arms with hardware shown.



IN-LK-P-RAN1K-6 / IN-LK-P-RAN1K-6-001 / IN-LK-P-RAN1K-6-002

CAMBER

- Tires must have equal air pressure before making adjustments.
- Adjustments to be made after all suspension components have been completely assembled.
- Tires must not be in contact with ground when making adjustments.
- Perform adjustments in small increments.



Adjusting Camber:

- Remove A-Arms from Frame and turn Pivot Blocks to adjust camber. Reinstall Arms.
- Lower machine and settle suspension components by rolling machine back and forth several feet at a time.
- Check settings and make small adjustments as needed.
- Each time an adjustment is made, machine must be rolled back and forth to settle suspension components.
- Once desired setting is achieved, tighten hardware completely. Loc-tite on Nuts is recommended.

A NEGATIVE CAMBER SETTING OF 1° to 2° IS RECOMMENDED.

LOWER:

Too much positive camber: adjust Pivot Blocks *OUT*. Too much negative camber: adjust Pivot Blocks *IN*. *note: 2 full turns is 1*°

UPPER A-ARMS:

Too much positive camber: adjust Pivot Blocks *IN*. Too much negative camber: adjust Pivot Blocks *OUT*. *note: 2 full turns is 1*°

