

***FREE SHIPPING ON ORDERS OVER \$98 (EXCLUSIONS APPLY)**[SHOP CATEGORIES](#)[WHY S&B](#)[SHOP BY VEHICLE](#)

0

INSTALL INSTRUCTIONS FOR AS-1014

 [PRINT](#)

BEFORE YOU START

Note: This intake kit may not fit with the following Aftermarket Parts installed:

- Body Lift or Lowering Kit
- Custom Hood
- Intercooler or Turbo upgrades

If at any point in the instructions it is difficult to access the scoops or hood liner. Open the hood completely until the hood rests on the cabin (place a blanket or towel in between to avoid damage). Use a step stool or ladder to reach. Also, it is optional to remove the hood by removing the 4 hood bolts. See the manufacturer's instructions for removing the hood. These instructions will guide you to install the S&B Hood Scoops without needing to remove the hood



REQUIRED TOOLS

- Panel Popper
- Scissors
- Marker
- Box Cutter / Knife
- Strong Duct Tape
- Gloves
- Blanket or Towel
- T20 Torx bit and driver
- Phillips Head Screwdriver (Optional)
- Flat Head Screwdriver
- Step Stool /Step Ladder



Hi. Need any help?

[Cookie Preferences](#)




ITEM	QTY.	DESCRIPTION	PART NUMBER
A	1	Passengers Side Hood Scoop, Top Side	Ai2220-00
B	1	Passengers Side Hood Scoop, Under Side	Ai2221-00
C	1	Drivers Side Hood Scoop, Top Side	Ai2216-00
D	1	Drivers Side Hood Scoop, Under Side	Ai2217-00
E	1	Passengers Side Scoop Plug	Ai2223-00
F	1	Drivers Side Scoop Plug	Ai2222-00
G	8	M4 Zinc Plated Washers	Ai2245-00
H	4	M4 x 14 mm Zinc Button Head Torx Screws	Ai2224-00
I	1	Hood Scoop Tube	AL1349-00
J	4	M4 x 20 mm Zinc Button Head Torx Screws	Ai2276-00
K	1	Silicone Check Valve	Ai2275C-00
L	4	10-24 x 5/8" Phillips Screws	Ai2005-00
M	4	#10 Counter Sunk Washers	Ai2057-00
N	1	Airbox Scoop Seal	Ai2270C-00
O	1	Airbox Plug	Ai2274C-00
P	12	Hood Liner Rivets	AI1567-00
Q	2	M4 x 0.7 mm x 50 mm Long Threaded Rods	AI2431-00
R	2	M4 Winged Nut	AI2474-00

TIP 1


If at any point in the instructions it is difficult to access the scoops or hood liner. Open the hood completely until the hood rests on the cabin (place a blanket or towel in between to avoid damage). Use a step

Cookie Preferences ader to reach. Also,

it is optional to remove the hood by removing the 4 hood bolts. See the manufacturer's instructions for removing the hood. These instructions will guide you to install the S&B Hood Scoops without needing to remove the hood.



TIP 2



STEP 2

With the hood open, using a panel popper: remove the push-in rivets holding the hood liner/ insulation in place.

There are 12 in total. A step stool will be required to reach. S&B supplies factory fit replacement hood liner

in the kit in case any are damaged. Once all

rivets have been removed set
the hood liner to the side.



STEP 2A

With the liner removed.
Remove the factory hood
bezels.

Cookie Preferences

STEP 2B

Pinch the six holding tabs inward towards the body of the bezel to release the bezels from the hood. If needed, a flat head screwdriver can be used to wedge these snap-in features.

STEP 3A

Locate the printed cut template. Set the hood liner on the working surface with the silver side facing up.

STEP 3B

Cookie Preferences

With a pair of scissors cut within the line of the provided paper template.

STEP 3C

After cutting the template check with a hood scoop top side (A and C) that the cut template has sufficient clearance for the inserts

STEP 3D

Align the template with the indentation of the factory vents on the hood liner. Tape down the template if needed

Cookie Preferences

STEP 3E

Using a marker, trace within the template onto the silver side of the hood liner. Hold down the edges of the paper template close to the surface for a better trace.

STEP 4

Remove the template from the liner if taped down. Using a blade or knife. Cut on the line of the traced pattern. For

[Cookie Preferences](#) cut in a sawing motion to produce a clean

cut. It is suggested to wear gloves when handling the exposed cut hood liner as this can irritate the skin on contact.

STEP 5

Flip over the paper template and Repeat Step 3-4 for the opposite scoop opening.

STEP 6

Insert the two provided threaded rods (Q) by hand onto one of the top sides of the hood scoops (A or C) with inserts at the topmost and bottommost insert locations at opposite corners.

Cookie Preferences

STEP 7

Align one of the S&B Hood scoops tops through the hood liner. Make sure the inserts and threaded rods are unobstructed. Adjust the cut for clearance as needed.

STEP 8

Remove the threaded rods by hand from the hood scoop top and insert them into the other hood scoop. repeat

Cookie Preferences

STEP 9

Once the cuts are done.

Reattach the hood liner to the vehicle. Push in a Hood liner rivet (P) in each corner. This will make it easier to remove the liner in case adjustments need to be made.

STEP 10

Close the hood. Set down a hood scoop top (A or C) with the threaded rods installed

[Cookie Preferences](#) atching openings on the hood. For ease of

assembly on the next step
tape the scoops down onto
the hood firmly.

STEP 11A

Open the hood with the Hood
Scoop top taped down
securely. Select your
passenger's side airflow
option

STEP 11B

If you are connecting to an
S&B intake, connect the
silicone check valve (K) onto
the hood scoop tube (I).
Place the hood scoop tube

Cookie Preferences Headed rods (Q)

STEP 11C

If you are connecting the vents only version; install the passenger's side hood scoop, underside (B) over the threaded rods (Q)

STEP 12A

For easier alignment
Compress the hood liner by
tightening down with the
provided wing nuts (R).

Cookie Preferences

STEP 12B

If access is difficult to turn the wingnut a driver tool can be used to tighten down.

STEP 13A

Depending on your selection in step 11, connect the underside of the scoops using a T20 Torx bit and driver into place using the two available positions. Tighten down until the liner is compressed and

Cookie Preferences jacket seals to the

hood. Recommended torque specification 10-15 in. lbs.

STEP 13B

To connect the Hood scoop Tube (I) use the M4 x 20mm (Long) screws (J) and M4 washers (G).

STEP 13C

To connect the passenger's side hood scoop, underside (B) use the M4 x 14mm (Short) screws (H) and M4 washers (G)

Cookie Preferences

STEP 14A

Once the screws are tightened in the two positions, remove the threaded rods by hand one at a time and replace it with appropriate hardware in the available positions. Tighten down firmly.

STEP 14B

Tighten down all of the screws firmly.

Cookie Preferences

STEP 15

Repeat Steps 9-14 for the other side

STEP 16

Once you are satisfied with the alignment of the scoops and liner. Make sure all of the screws are firmly tightened.

Replace remaining push-in rivets securing the hood liner to the hood

Cookie Preferences

STEP 17

Close the hood. Remove the tape holding down the hood scoops. The installation of the vents is now complete. For further instructions on attaching to an S&B intake see “ S&B Intake specific instructions”.

HOOD SCOOP PLUGS INSTALLATION

If extreme weather conditions arise such as heavy snow, dust or other debris grill plugs have been provided to prevent these elements from entering the hood scoops.

STEP 1

Locate the scoop plugs included with the kit (E & F)

STEP 2

Position the appropriate ~~scoop plug~~ in front of the Cookie Preferences using scoop (A & C).

STEP 3

Make sure all the lower prong features of the plug are located into the appropriate grill features

STEP 4

Align the topmost prongs with the corresponding grill feature

Cookie Preferences

STEP 5

Push the plug into the grill

STEP 6

To remove plugs pull from the innermost corner of the plug and peel away from the grill

STEP 7

Repeat steps 1-6 for the other hood scoop. Installation is

Cookie Preferences [Cookie Preferences](#)

S&B INTAKE SPECIFIC INSTRUCTIONS

STEP 1

Install or confirm S&B Filters
Intake kit 75-5121 or 75-5129
is installed; install or confirm
the S&B Hood Scoop Tube (I)
is installed

Cookie Preferences

STEP 2

Decide whether or not to attach to replace the intake fender seal with the optional silicone airbox plug (O) to the side of the S&B airbox.

STEP 3

With a Phillips head screwdriver remove the polycarbonate lid hardware and lid from the installed intake.

STEP 4

Remove the lid seal from the

Cookie Preferences the airbox

STEP 5

Place the hood scoop airbox lid seal (N) onto the airbox

STEP 6

Place the washers (M) and Screws (L) provided into the countersunk holes in the lid seal and tighten down using a Phillips head screw.

STEP 7

Close the hood to check the alignment of the hood scoop tube onto the airbox scoop seal (N). If needed, adjust the scoop by loosening the hardware with a T20 Torx bit and driver so that it is aligned with the silicone airbox seal. When in a desirable position tighten down the hardware securely.

STEP 8

Close the hood.

STEP 9

Installation is complete.

Cookie Preferences